MSI
MICRO-STAR INTERNATIONAL

P35 Platinum Combo series

MS-7338 (v1.X) Mainboard



Copyright Notice

The material in this document is the intellectual property of **MICRO-STAR INTERNATIONAL**. We take every care in the preparation of this document, but no guarantee is given as to the correctness of its contents. Our products are under continual improvement and we reserve the right to make changes without notice.

Trademarks

All trademarks are the properties of their respective owners.

NVIDIA, the NVIDIA logo, DualNet, and nForce are registered trademarks or trademarks of NVIDIA Corporation in the United States and/or other countries.
AMD, Athlon™, Athlon™ XP, Thoroughbred™, and Duron™ are registered trademarks of AMD Corporation.
Intel® and Pentium® are registered trademarks of Intel Corporation.
PS/2 and OS®/2 are registered trademarks of International Business Machines Corporation.
Windows® 95/98/2000/NT/XP/Vista are registered trademarks of Microsoft Corporation.
Netware® is a registered trademark of Novell, Inc.
Award® is a registered trademark of Phoenix Technologies Ltd.
AMI® is a registered trademark of American Megatrends Inc.

Revision History

Revision	Revision History	Date
V1.0	First release for P35	June 2007

Technical Support

If a problem arises with your system and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please try the following help resources for further guidance.

- Visit the MSI website for FAQ, technical guide, BIOS updates, driver updates, and other information: ***http://global.msi.com.tw/index.php?func=faqIndex***
- Contact our technical staff at: ***http://support.msi.com.tw/***

Safety Instructions

1. Always read the safety instructions carefully.
2. Keep this User's Manual for future reference.
3. Keep this equipment away from humidity.
4. Lay this equipment on a reliable flat surface before setting it up.
5. The openings on the enclosure are for air convection hence protects the equipment from overheating. DO NOT COVER THE OPENINGS.
6. Make sure the voltage of the power source and adjust properly 110/220V before connecting the equipment to the power inlet.
7. Place the power cord such a way that people can not step on it. Do not place anything over the power cord.
8. Always Unplug the Power Cord before inserting any add-on card or module.
9. All cautions and warnings on the equipment should be noted.
10. Never pour any liquid into the opening that could damage or cause electrical shock.
11. If any of the following situations arises, get the equipment checked by a service personnel:
    - † The power cord or plug is damaged.
    - † Liquid has penetrated into the equipment.
    - † The equipment has been exposed to moisture.
    - † The equipment has not work well or you can not get it work according to User's Manual.
    - † The equipment has dropped and damaged.
    - † The equipment has obvious sign of breakage.
12. DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT UNCONDITIONED, STORAGE TEMPERATURE ABOVE 60^0C (140^0F), IT MAY DAMAGE THE EQUIPMENT.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

警告使用者:
這是甲類的資訊產品，在居住的環境中使用時，可能會造成無線電干擾，在這種情況下，使用者會被要求採取某些適當的對策。

廢電池請回收

For better environmental protection, waste batteries should be collected separately for recycling or special disposal.

FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below.

CE N1996

- † Reorient or relocate the receiving antenna.
- † Increase the separation between the equipment and receiver.
- † Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- † Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and A.C. power cord, if any, must be used in order to comply with the emission limits.

VOIR LA NOTICE D'INSTALLATION AVANT DE RACCORDER AU RESEAU.

FC **Micro-Star International**
MS-7338

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

WEEE (Waste Electrical and Electronic Equipment) Statement

ENGLISH

To protect the global environment and as an environmentalist, MSI must remind you that...

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2002/96/EC, which takes effect on August 13, 2005, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life. MSI will comply with the product take back requirements at the end of life of MSI-branded products that are sold into the EU. You can return these products to local collection points.

DEUTSCH

Hinweis von MSI zur Erhaltung und Schutz unserer Umwelt

Gemäß der Richtlinie 2002/96/EG über Elektro- und Elektronik-Altgeräte dürfen Elektro- und Elektronik-Altgeräte nicht mehr als kommunale Abfälle entsorgt werden. MSI hat europaweit verschiedene Sammel- und Recyclingunternehmen beauftragt, die in die Europäische Union in Verkehr gebrachten Produkte, am Ende seines Lebenszyklus zurückzunehmen. Bitte entsorgen Sie dieses Produkt zum gegebenen Zeitpunkt ausschliesslich an einer lokalen Altgerätesammelstelle in Ihrer Nähe.

FRANÇAIS

En tant qu'écologiste et afin de protéger l'environnement, MSI tient à rappeler ceci...

Au sujet de la directive européenne (EU) relative aux déchets des équipement électriques et électroniques, directive 2002/96/EC, prenant effet le 13 août 2005, que les produits électriques et électroniques ne peuvent être déposés dans les décharges ou tout simplement mis à la poubelle. Les fabricants de ces équipements seront obligés de récupérer certains produits en fin de vie. MSI prendra en compte cette exigence relative au retour des produits en fin de vie au sein de la communauté européenne. Par conséquent vous pouvez retourner localement ces matériels dans les points de collecte.

РУССКИЙ

Компания MSI предпринимает активные действия по защите окружающей среды, поэтому напоминаем вам, что....

В соответствии с директивой Европейского Союза (ЕС) по предотвращению загрязнения окружающей среды использованным электрическим и электронным оборудованием (директива WEEE 2002/96/EC), вступающей в силу 13 августа 2005 года, изделия, относящиеся к электрическому и электронному оборудованию, не могут рассматриваться как бытовой мусор, поэтому производители вышеперечисленного электронного оборудования обязаны принимать его для переработки по окончании срока службы. MSI обязуется соблюдать требования по приему продукции, проданной под маркой MSI на территории ЕС, в переработку по окончании срока службы. Вы можете вернуть эти изделия в специализированные пункты приема.

ESPAÑOL

MSI como empresa comprometida con la protección del medio ambiente, recomienda:
Bajo la directiva 2002/96/EC de la Unión Europea en materia de desechos y/o equipos electrónicos, con fecha de rigor desde el 13 de agosto de 2005, los productos clasificados como "eléctricos y equipos electrónicos" no pueden ser depositados en los contenedores habituales de su municipio, los fabricantes de equipos electrónicos, están obligados a hacerse cargo de dichos productos al termino de su período de vida. MSI estará comprometido con los términos de recogida de sus productos vendidos en la Unión Europea al final de su periodo de vida. Usted debe depositar estos productos en el punto limpio establecido por el ayuntamiento de su localidad o entregar a una empresa autorizada para la recogida de estos residuos.

NEDERLANDS

Om het milieu te beschermen, wil MSI u eraan herinneren dat....
De richtlijn van de Europese Unie (EU) met betrekking tot Vervuiling van Electrische en Electronische producten (2002/96/EC), die op 13 Augustus 2005 in zal gaan kunnen niet meer beschouwd worden als vervuiling.
Fabrikanten van dit soort producten worden verplicht om producten retour te nemen aan het eind van hun levenscyclus. MSI zal overeenkomstig de richtlijn handelen voor de producten die de merknaam MSI dragen en verkocht zijn in de EU. Deze goederen kunnen geretourneerd worden op lokale inzamelingspunten.

SRPSKI

Da bi zaštitili prirodnu sredinu, i kao preduzeće koje vodi računa o okolini i prirodnoj sredini, MSI mora da vas podesti da...
Po Direktivi Evropske unije ("EU") o odbačenoj ekektronskoj i električnoj opremi, Direktiva 2002/96/EC, koja stupa na snagu od 13. Avgusta 2005, proizvodi koji spadaju pod "elektronsku i električnu opremu" ne mogu više biti odbačeni kao običan otpad i proizvođači ove opreme biće prinuđeni da uzmu natrag ove proizvode na kraju njihovog uobičajenog veka trajanja. MSI će poštovati zahtev o preuzimanju ovakvih proizvoda kojima je istekao vek trajanja, koji imaju MSI oznaku i koji su prodati u EU. Ove proizvode možete vratiti na lokalnim mestima za prikupljanje.

POLSKI

Aby chronić nasze środowisko naturalne oraz jako firma dbająca o ekologię, MSI przypomina, że...
Zgodnie z Dyrektywą Unii Europejskiej ("UE") dotyczącą odpadów produktów elektrycznych i elektronicznych (Dyrektywa 2002/96/EC), która wchodzi w życie 13 sierpnia 2005, tzw. "produkty oraz wyposażenie elektryczne i elektroniczne " nie mogą być traktowane jako śmieci komunalne, tak więc producenci tych produktów będą zobowiązani do odbierania ich w momencie gdy produkt jest wycofywany z użycia. MSI wypełni wymagania UE, przyjmując produkty (sprzedawane na terenie Unii Europejskiej) wycofywane z użycia. Produkty MSI będzie można zwracać w wyznaczonych punktach zbiorczych.

TÜRKÇE

Çevreci özelliğiyle bilinen MSI dünyada çevreyi korumak için hatırlatır:

Avrupa Birliği (AB) Kararnamesi Elektrik ve Elektronik Malzeme Atığı, 2002/96/EC Kararnamesi altında 13 Ağustos 2005 tarihinden itibaren geçerli olmak üzere, elektrikli ve elektronik malzemeler diğer atıklar gibi çöpe atılamayacak ve bu elektonik cihazların üreticileri, cihazların kullanım süreleri bitttikten sonra ürünleri geri toplamakla yükümlü olacaktır. Avrupa Birliği'ne satılan MSI markalı ürünlerin kullanım süreleri bittiğinde MSI ürünlerin geri alınması isteği ile işbirliği içerisinde olacaktır. Ürünlerinizi yerel toplama noktalarına bırakabilirsiniz.

ČESKY

Záleží nám na ochraně životního prostředí - společnost MSI upozorňuje...

Podle směrnice Evropské unie ("EU") o likvidaci elektrických a elektronických výrobků 2002/96/EC platné od 13. srpna 2005 je zakázáno likvidovat "elektrické a elektronické výrobky" v běžném komunálním odpadu a výrobci elektronických výrobků, na které se tato směrnice vztahuje, budou povinni odebírat takové výrobky zpět po skončení jejich životnosti. Společnost MSI splní požadavky na odebírání výrobků značky MSI, prodávaných v zemích EU, po skončení jejich životnosti. Tyto výrobky můžete odevzdat v místních sběrnách.

MAGYAR

Annak érdekében, hogy környezetünket megvédjük, illetve környezetvédőként fellépve az MSI emlékezteti Önt, hogy ...

Az Európai Unió („EU") 2005. augusztus 13-án hatályba lépő, az elektromos és elektronikus berendezések hulladékairól szóló 2002/96/EK irányelve szerint az elektromos és elektronikus berendezések többé nem kezelhetőek lakossági hulladékként, és az ilyen elektronikus berendezések gyártói kötelessé válnak az ilyen termékek visszavételére azok hasznos élettartama végén. Az MSI betartja a termékvisszavétellel kapcsolatos követelményeket az MSI márkanév alatt az EU-n belül értékesített termékek esetében, azok élettartamának végén. Az ilyen termékeket a legközelebbi gyűjtőhelyre viheti.

ITALIANO

Per proteggere l'ambiente, MSI, da sempre amica della natura, ti ricorda che....

In base alla Direttiva dell'Unione Europea (EU) sullo Smaltimento dei Materiali Elettrici ed Elettronici, Direttiva 2002/96/EC in vigore dal 13 Agosto 2005, prodotti appartenenti alla categoria dei Materiali Elettrici ed Elettronici non possono più essere eliminati come rifiuti municipali: i produttori di detti materiali saranno obbligati a ritirare ogni prodotto alla fine del suo ciclo di vita. MSI si adeguerà a tale Direttiva ritirando tutti i prodotti marchiati MSI che sono stati venduti all'interno dell'Unione Europea alla fine del loro ciclo di vita. È possibile portare i prodotti nel più vicino punto di raccolta.

CONTENTS

Copyright Notice ii
Trademarks ii
Revision History ii
Technical Support ii
Safety Instructions iii
FCC-B Radio Frequency Interference Statement iv
WEEE (Waste Electrical and Electronic Equipment) Statement v
Chapter 1. Getting Started 1-1
Mainboard Specifications 1-2
Mainboard Layout 1-4
Packing Checklist 1-5
Chapter 2. Hardware Setup 2-1
Quick Components Guide 2-2
CPU (Central Processing Unit) 2-3
Memory 2-7
Power Supply 2-10
Back Panel 2-11
Connectors 2-13
Jumper 2-20
Button 2-21
Slots 2-22
LED Status Indicators 2-24
Chapter 3 BIOS Setup 3-1
Entering Setup 3-2
The Main Menu 3-4
Standard CMOS Features 3-6
Advanced BIOS Features 3-9
Integrated Peripherals 3-12
Power Management Setup 3-14
PNP/PCI Configurations 3-17
H/W Monitor 3-19
Cell Menu 3-20
Load Fail-Safe/ Optimized Defaults 3-26
BIOS Setting Password 3-27
Realtek ALC888/888T Audio Appendix A A-1
Installing the Realtek HD Audio Driver A-2
Software Configuration A-4
Hardware Setup A-18

Appendix B Dual Core Center B-1
Activating Dual Core Center B-2
Main B-2
DOT (Dynamic OverClocking) B-5
Clock B-6
Voltage B-7
FAN Speed B-8
Temperature B-9
User Profile B-10
Appendix C Intel ICH9R SATA RAID C-1
ICH9R Introduction C-2
BIOS Configuration C-3
Installing Driver C-9
Installing Software C-11
RAID Migration Instructions C-15
Degraded RAID Array C-22

Chapter 1
Getting Started

Thank you for choosing the P35 Platinum Combo Series (MS-7338 v1.X) ATX mainboard. The P35 Platinum Combo Series mainboards are based on **Intel® P35 & ICH9R** chipsets for optimal system efficiency. Designed to fit the advanced **Intel® Core 2 Quad/Core 2 Duo/ Pentium/Celeron LGA775** processor, the P35 Platinum Combo Series deliver a high performance and professional desktop platform solution.

MSI
MICRO-STAR INTERNATIONAL

Mainboard Specifications

Processor Support

- Intel® Core 2 Quad/Core 2 Duo/Pentium/Celeron processors in the LGA775 package
- Support Intel® Yorkfield, Wolfdale
  (For the latest information about CPU, please visit http://global.msi.com.tw/index.php?func=cpuform)

Supported FSB

- 1333/ 1066/ 800 MHz

Chipset

- North Bridge: Intel® P35 chipset
- South Bridge: Intel® ICH9R chipset

Memory Support

- 4 DDR2 DIMMs support DDR2 800/ 667 SDRAM (240pin / 1,8V / 8GB Max)
- 2 DDR3 DIMMs support DDR3 1066/ 800 SDRAM (240pin / 1.5V / 4GB Max)
  (For more information on compatible components, please visit http://global.msi.com.tw/index.php?func=testreport)

LAN

- Supports PCIE LAN 10/100/1000 Fast Ethernet by Realtek 8111B

Audio

- Chip integrated by Realtek® ALC888/ALC888T
- Flexible 8-channel audio with jack sensing
- Compliant with Azalia 1.0 Spec
- Meet Microsoft Vista Premium spec
- Supports VoIP Card (only for ALC888T)

IDE

- 1 IDE port by Marvell 88SE6111
- Supports Ultra DMA 66/100/133 mode
- Supports PIO, Bus Master operation mode

SATA

- 4 SATAII ports plus 2 eSATA by ICH9R
- 1 SATA II port by Marvell 88SE6111
- Supports storage and data transfers at up to 300 MB/s

RAID

- Supports Intel Martix Storage Technology (AHCI + RAID 0/1/5/10) by ICH9R

1394 (optional)

- Supports 1394 by VIA VT6308

FDD

- 1 floppy port
- Supports 1 FDD with 360KB, 720KB, 1.2MB, 1.44MB and 2.88MB

Connectors

- **Back panel**
  - 1 PS/2 mouse port
  - 1 PS/2 keyboard port
  - 2 eSATA ports (support Command Based Port Multipliers)
  - 6 USB 2.0 Ports
  - 1 LAN jack (10/100/1000)
  - 6 flexible audio jacks
  - 1 1394 port (optional)
  - 1 Optical S/PDIF-Out (optional)

- **On-Board Pinheaders / Connectors**
  - 3 USB 2.0 pinheaders
  - 1 1394 pinheader (optional)
  - 1 chasis intrusion connector
  - 1 SPDIF-out pinheader
  - 1 CD-in connector
  - 2 H/W OC pinheaders (optional)
  - 1 front audio pinheader
  - 1 serial pinheader

Slots

- 1 PCI Express x16 slot
- 2 PCI Express x1 slots
- 1 PCI Express x4 slot
- 2 PCI slots
- Support 3.3V/ 5V PCI bus Interface

Form Factor

- ATX (30.5cm X 24.5cm)

Mounting

- 9 mounting holes

Mainboard Layout



P35 Platinum Combo Series
(MS-7338 v1.X) ATX Mainboard

Packing Checklist


MSI motherboard


MSI Driver/Utility CD

Back IO Shield

Power Cable

SATA Cable

IDE Cable

Floppy Cable

external SATA Cable (Optional)

1394 Bracket (Optional)

User's Guide and Quick Guide


ATX Extender (Optional)


DDR2/DDR3 Turbo Card

* The pictures are for reference only and may vary from the packing contents of the product you purchased.

Chapter 2
Hardware Setup

This chapter provides you with the information about hardware setup procedures. While doing the installation, be careful in holding the components and follow the installation procedures. For some components, if you install in the wrong orientation, the components will not work properly.

Use a grounded wrist strap before handling computer components. Static electricity may damage the components.

MSI
MICRO-STAR INTERNATIONAL

Quick Components Guide



CPU (Central Processing Unit)

When you are installing the CPU, **make sure to install the cooler to prevent overheating.** If you do not have the CPU cooler, consult your dealer before turning on the computer.
For the latest information about CPU, please visit *http://global.msi.com.tw/index.php?func=cpuform*

Important

Overheating
Overheating will seriously damage the CPU and system. Always make sure the cooling fan can work properly to protect the CPU from overheating. Make sure that you apply an even layer of thermal paste (or thermal tape) between the CPU and the heatsink to enhance heat dissipation.
Replaceing the CPU
While replacing the CPU, always turn off the ATX power supply or unplug the power supply's power cord from the grounded outlet first to ensure the safety of CPU.
Overclocking
This mainboard is designed to support overclocking. However, please make sure your components are able to tolerate such abnormal setting, while doing overclocking. Any attempt to operate beyond product specifications is not recommended. ***We do not guarantee the damages or risks caused by inadequate operation or beyond product specifications.***

Introduction to LGA 775 CPU

The pin-pad side of LGA 775 CPU.



Yellow triangle is the Pin 1 indicator

The surface of LGA 775 CPU. Remember to apply some thermal paste on it for better heat dispersion.



Yellow triangle is the Pin 1 indicator

CPU & Cooler Installation

When you are installing the CPU, **make sure the CPU has a cooler attached on the top to prevent overheating.** Meanwhile, do not forget to apply some thermal paste on CPU before installing the heat sink/cooler fan for better heat dispersion. Follow the steps below to install the CPU & cooler correctly. Wrong installation will cause the damage of your CPU & mainboard.

1. The CPU socket has a plastic cap on it to protect the contact from damage. Before you install the CPU, always cover it to protect the socket pin.



2. Remove the cap from lever hinge side (as the arrow shows).



3. The pins of socket reveal.



4. Open the load lever.



Important

1. Confirm if your CPU cooler is firmly installed before turning on your system.
2. Do not touch the CPU socket pins to avoid damaging.
3. The availability of the CPU land side cover depends on your CPU packing.

5. Lift the load lever up and open the load plate.



6. After confirming the CPU direction for correct mating, put down the CPU in the socket housing frame. Be sure to grasp on the edge of the CPU base. Note that the alignment keys are matched.



7. Visually inspect if the CPU is seated well into the socket. If not, take out the CPU with pure vertical motion and reinstall.



8. Cover the load plate onto the package.



9. Press down the load lever lightly onto the load plate, and then secure the lever with the hook under retention tab.



10. Align the holes on the mainboard with the heatsink. Push down the cooler until its four clips get wedged into the holes of the mainboard.



11. Press the four hooks down to fasten the cooler. Then rotate the locking switch (refer to the correct direction marked on it) to lock the hooks.



12. Turn over the mainboard to confirm that the clip-ends are correctly inserted.



Important

1. Read the CPU status in BIOS (Chapter 3).
2. Whenever CPU is not installed, always protect your CPU socket pin with the plastic cap covered (shown in Figure 1) to avoid damaging.
3. Mainboard photos shown in this section are for demonstration of the CPU/ cooler installation only. The appearance of your mainboard may vary depending on the model you purchase.

Memory

These DIMM slots are used for installing memory modules.
Since DDR3 modules are not interchangeable with DDR2 and the DDR3 standard is not backward compatible, you should always install DDR3 memory module in DDR3 slot (DIMM_DDR3_1~2), and DDR2 memory module in DDR2 slot (DIMM_DDR2_1~4). Wrong installation may cause damage of mainboard. Meanwhile, you are not able to boot up your system if you install DDR2 & DDR3 memory modules simultaneously.
For more information on compatible components, please visit *http://global.msi.com.tw/index.php?func=testreport*

DIMM_DDR2_1~4 are for DDR2 memory module

Dual-Channel: Channel A in GREEN; Channel B in ORANGE



DIMM_DDR3_1~2 are for DDR3 memory module

Dual-Channel: Channel A inSKYBLUE; Channel B in PINK

Dual-Channel mode Population Rule

In Dual-Channel mode, the memory modules can transmit and receive data with two data bus lines simultaneously. Enabling Dual-Channel mode can enhance the system performance. Please refer to the following illustrations for population rules under Dual-Channel mode.

1



Dual channel mode population rule for DDR2 (Install two DDR2/DDR3 Turbo Cards in the DIMM_DDR3_1 and DIMM_DDR3_2 slots)

2



Dual channel mode population rule for DDR2 (Install two DDR2/DDR3 Turbo Cards in the DIMM_DDR3_1 and DIMM_DDR3_2 slots)

3

Dual channel mode population rule for DDR2 (Install two DDR2/DDR3 Turbo Cards in the DIMM_DDR3_1 and DIMM_DDR3_2 slots)

4



Dual channel mode population rule for DDR3 (Install two DDR2/DDR3 Turbo Cards in the DIMM_DDR2_2 and DIMM_DDR2_4 slots)

Installing Memory Modules

1. The memory module has only one notch on the center and will only fit in the right orientation.
2. Insert the memory module vertically into the DIMM slot. Then push it in until the golden finger on the memory module is deeply inserted in the DIMM slot.

Important

You can barely see the golden finger if the memory module is properly inserted in the DIMM slot.

3. The plastic clip at each side of the DIMM slot will automatically close.



Installing DDR2/DDR3 Turbo Card

The DDR2/DDR3 Turbo Cards are memory switchers which should be installed in DIMM slots. If your memory is DDR2, you should install the DIMM_DDR3_1 side of DDR2/DDR3 Turbo Cards into DIMM_DDR3_1 and DIMM_DDR3_2. If your memory is DDR3, you should install the DIMM_DDR2_1 side of DDR2/DDR3 Turbo Cards into DIMM_DDR2_2 and DIMM_DDR2_4.



DDR2/DDR3 Turbo Card

When system memory is DDR2



When system memory is DDR3



Important

- *In Dual-Channel mode, make sure that you install memory modules of **the same type and density** in different channel DIMM slots.*
- *To enable successful system boot-up, always insert the memory modules into the **DIMM_DDR2_1** or **DIMM_DDR3_1** first.*
- *To overclock your DDR3 memory and raise FSB higher then 1333MHz, you must remove the DDR2/DDR3 Turbo Cards from the DIMM slots.*

Power Supply

ATX 24-Pin Power Connector: JPWR3

This connector allows you to connect an ATX 24-pin power supply. To connect the ATX 24-pin power supply, make sure the plug of the power supply is inserted in the proper orientation and the pins are aligned. Then push down the power supply firmly into the connector.

You may use the 20-pin ATX power supply as you like. If you'd like to use the 20-pin ATX power supply, please plug your power supply along with pin 1 & pin 13 (refer to the image at the right hand).





Pin Definition

PIN	SIGNAL	PIN	SIGNAL
1	+3.3V	13	+3.3V
2	+3.3V	14	-12V
3	GND	15	GND
4	+5V	16	PS-ON#
5	GND	17	GND
6	+5V	18	GND
7	GND	19	GND
8	PWROK	20	Res
9	5VSB	21	+5V
10	+12V	22	+5V
11	+12V	23	+5V
12	+3.3V	24	GND

ATX 5V / 12V Power Connector: JPWR2 / JPWR1

The JPWR2 12V power connector is used to provide power to the CPU. And the JPWR1 5V / 12V power connector is used to provide power to the PCIEX16 graphics card.



JPWR2

Pin Definition

PIN	SIGNAL	PIN	SIGNAL
1	GND	5	+12V
2	GND	6	+12V
3	GND	7	+12V
4	GND	8	+12V



JPWR1

Pin Definition

PIN	SIGNAL
1	5V
2	GND
3	GND
4	12V

Important

1. *Make sure that all the connectors are connected to proper ATX power supplies to ensure stable operation of the mainboard.*
2. *Power supply of 350 watts (and above) is highly recommended for system stability.*
3. *ATX 12V power connection should be greater than 18A.*
4. *If the JPWR2 connector too closes the heatpipe and plug inconveniently. You could use the bundled ATX Extender to increase connector height. It can prevent the power cable to touch the heatpipe as well.*

Back Panel



▶ Mouse/Keyboard
The standard PS/2® mouse/keyboard DIN connector is for a PS/2® mouse/keyboard.

▶ 1394 Port (Optional)
The IEEE1394 port on the back panel provides connection to IEEE1394 devices.

▶ Optical S/PDIF-Out (Optional)
This SPDIF (Sony & Philips Digital Interconnect Format) connector is provided for digital audio transmission to external speakers through an optical fiber cable.

▶ USB Port
The USB (Universal Serial Bus) port is for attaching USB devices such as keyboard, mouse, or other USB-compatible devices.

▶ LAN
The standard RJ-45 LAN jack is for connection to the Local Area Network (LAN). You can connect a network cable to it.



LED	Color	LED State	Condition
Left	Yellow	Off	LAN link is not established.
		On (steady state)	LAN link is established.
		On (brighter & pulsing)	The computer is communicating with another computer on the LAN.
Right	Green	Off	10 Mbit/sec data rate is selected.
		On	100 Mbit/sec data rate is selected.
	Orange	On	1000 Mbit/sec data rate is selected.

► Audio Ports

These audio connectors are used for audio devices. You can differentiate the color of the audio jacks for different audio sound effects.

- **Line-In (Blue)** - Line In is used for external CD player, tapeplayer or other audio devices.
- **Line-Out (Green)** - Line Out, is a connector for speakers or headphones.
- **Mic (Pink)** - Mic, is a connector for microphones.
- **RS-Out (Black)** - Rear-Surround Out in 4/ 5.1/ 7.1 channel mode.
- **CS-Out (Orange)** - Center/ Subwoofer Out in 5.1/ 7.1 channel mode.
- **SS-Out (Gray)** - Side-Surround Out 7.1 channel mode.

► eSATA Port

The eSATA port is for attaching the eSATA external hard drive.

Connectors

Floppy Disk Drive Connector: FDD1

This connector supports 360KB, 720KB, 1.2MB, 1.44MB or 2.88MB floppy disk drive.



IDE Connector: IDE1

This connector supports IDE hard disk drives, optical disk drives and other IDE devices.



Important

If you install two IDE devices on the same cable, you must configure the drives separately to master / slave mode by setting jumpers. Refer to IDE device's documentation supplied by the vendors for jumper setting instructions.

Serial ATA Connector: SATA1,2,5,6,7

This connector is a high-speed Serial ATA interface port. Each connector can connect to one Serial ATA device.



Important

Please do not fold the Serial ATA cable into 90-degree angle. Otherwise, data loss may occur during transmission.

VoIP Card Connector: JSLIC1 (Only for ALC888T)

This connector connects to the VoIP card. Please refer to the instruction of the VoIP card.



Fan Power Connectors: CPUFAN, SYSFAN1~5

The fan power connectors support system cooling fan with +12V. When connecting the wire to the connectors, always note that the red wire is the positive and should be connected to the +12V; the black wire is Ground and should be connected to GND. If the mainboard has a System Hardware Monitor chipset on-board, you must use a specially designed fan with speed sensor to take advantage of the CPU fan control.



Important

1. *Please refer to the recommended CPU fans at processor's official website or consult the vendors for proper CPU cooling fan.*
2. *CPUFAN supports fan control. You can install **Dual Core Center** utility that will automatically control the CPU fan speed according to the actual CPU temperature.*
3. *Fan cooler set with 3 or 4 pins power connector are both available for CPUFAN.*

Chassis Intrusion Connector: JCI1

This connector connects to the chassis intrusion switch cable. If the chassis is opened, the chassis intrusion mechanism will be activated. The system will record this status and show a warning message on the screen. To clear the warning, you must enter the BIOS utility and clear the record.

JCI1

IEEE1394 Connector: J1394_1(Optional)

This connector allows you to connect the IEEE1394 device via an optional IEEE1394 bracket.



J1394_1

Pin Definition

PIN	SIGNAL	PIN	SIGNAL
1	TPA+	2	TPA-
3	Ground	4	Ground
5	TPB+	6	TPB-
7	Cable power	8	Cable power
9	Key (no pin)	10	Ground



IEEE1394 Bracket (Optional)

S/PDIF-Out Connector: JSP1

This connector is used to connect S/PDIF (Sony & Philips Digital Interconnect Format) interface for digital audio transmission.





S/PDIF Bracket (Optional)

Front Panel Connectors: JFP1, JFP2

These connectors are for electrical connection to the front panel switches and LEDs. The JFP1 is compliant with Intel® Front Panel I/O Connectivity Design Guide.



JFP1 Pin Definition

PIN	SIGNAL	DESCRIPTION
1	HD_LED +	Hard disk LED pull-up
2	FP PWR/SLP	MSG LED pull-up
3	HD_LED -	Hard disk active LED
4	FP PWR/SLP	MSG LED pull-up
5	RST_SW -	Reset Switch low reference pull-down to GND
6	PWR_SW +	Power Switch high reference pull-up
7	RST_SW +	Reset Switch high reference pull-up
8	PWR_SW -	Power Switch low reference pull-down to GND
9	RSVD_DNU	Reserved. Do not use.

JFP2 Pin Definition

PIN	SIGNAL	DESCRIPTION
1	GND	Ground
2	SPK-	Speaker-
3	SLED	Suspend LED
4	BUZ+	Buzzer+
5	PLED	Power LED
6	BUZ-	Buzzer-
7	NC	No connection
8	SPK+	Speaker+

Front Panel Audio Connector: JAUD1

This connector allows you to connect the front panel audio and is compliant with Intel® Front Panel I/O Connectivity Design Guide.

JAUD1

HD Audio Pin Definition

PIN	SIGNAL	DESCRIPTION
1	MIC_L	Microphone - Left channel
2	GND	Ground
3	MIC_R	Microphone - Right channel
4	PRESENCE#	Active low signal-signals BIOS that a High Definition Audio dongle is connected to the analog header. PRESENCE# = 0 when a High Definition Audio dongle is connected
5	LINE out_R	Analog Port - Right channel
6	MIC_JD	Jack detection return from front panel microphone JACK1
7	Front_JD	Jack detection sense line from the High Definition Audio CODEC jack detection resistor network
8	NC	No control
9	LINE out_L	Analog Port - Left channel
10	LINEout_JD	Jack detection return from front panel JACK2

CD-In Connector: JCD1

This connector is provided for external audio input.



Front USB Connector: JUSB1 ~ 3

These connectors, compliant with Intel® I/O Connectivity Design Guide, is ideal for connecting high-speed USB interface peripherals such as **USB HDD**, **digital cameras**, **MP3 players**, **printers**, **modems and the like**.

JUSB1~3

Pin Definition

PIN	SIGNAL	PIN	SIGNAL
1	VCC	2	VCC
3	USB0-	4	USB1-
5	USB0+	6	USB1+
7	GND	8	GND
9	Key(no pin)	10	USBOC



USB 2.0 Bracket
(Optional)

Important

Note that the pins of VCC and GND must be connected correctly to avoid possible damage.

Serial Port Connector: JCOM 1

This connector is a 16550A high speed communication port that sends/receives 16 bytes FIFOs. You can attach a serial device.

JCOM1



Pin Definition

PIN	SIGNAL	DESCRIPTION
1	DCD	Data Carry Detect
2	SIN	Serial In or Receive Data
3	SOUT	Serial Out or Transmit Data
4	DTR	Data Terminal Ready
5	GND	Ground
6	DSR	Data Set Ready
7	RTS	Request To Send
8	CTS	Clear To Send
9	RI	Ring Indicate

Jumper

The motherboard provides the following jumper for you to set the computer's function. This section will explain how to change your motherboard's function through the use of jumper.

Hardware Overclock FSB Jumpers: JB1, JB2 (optional)

You can overclock the FSB to increase the processor frequency by changing the jumpers JB1 and JB2. Follow the instructions below to set the FSB.

JB1 JB2



200 MHz



266 MHz



333 MHz

Important

Make sure that you power off the system before changing the jumpers

Button

The motherboard provides the following button for you to set the computer's function. This section will explain how to change your motherboard's function through the use of button.

Clear CMOS Button: SW1

There is a CMOS RAM on board that has a power supply from external battery to keep the system configuration data. With the CMOS RAM, the system can automatically boot OS every time it is turned on. If you want to clear the system configuration, use the button to clear data. Press the button to clear the data.

SW1

Important

Make sure that you power off the system before clearing CMOS data.

Slots

PCI (Peripheral Component Interconnect) Express Slot

The PCI Express slot supports the PCI Express interface expansion card.
The PCI Express x 16 slot supports up to 4.0 GB/s transfer rate.
The PCI Express x 4 slot supports up to 1.0 GB/s transfer rate.
The PCI Express x 1 slot supports up to 250 MB/s transfer rate.



Important

The PCI_E2 and the PCI_E3 slots share 4 PCIE channels with the PCI_E4 slot. You could select the speed of the PCI_E4 slot in BIOS setup. Please refer to ***Chapter 3 BIOS Setup - Cell Menu - PCIEx4 Speed Controller****.*

PCI (Peripheral Component Interconnect) Slot

The PCI slot supports LAN card, SCSI card, USB card, and other add-on cards that comply with PCI specifications.



32-bit PCI Slot

Important

When adding or removing expansion cards, make sure that you unplug the power supply first. Meanwhile, read the documentation for the expansion card to configure any necessary hardware or software settings for the expansion card, such as jumpers, switches or BIOS configuration.

PCI Interrupt Request Routing

The IRQ, acronym of interrupt request line and pronounced I-R-Q, are hardware lines over which devices can send interrupt signals to the microprocessor. The PCI IRQ pins are typically connected to the PCI bus pins as follows:

	Order 1	Order 2	Order 3	Order 4
PCI Slot 1	INT A#	INT B#	INT C#	INT D#
PCI Slot 2	INT B#	INT C#	INT D#	INT A#

LED Status Indicators



Name	Status	Name	Status
LED1	Lights when DIMM_DDR3_1 slot is functional.	LED16	Lights when system is power-on.
LED2	Lights when DIMM_DDR3_2 slot is functional.	LED17	Lights when PCI_E1 slot is functional.
LED3	Lights when DIMM_DDR2_1 slot is functional.	LED18	Lights when PCI_E2 slot is functional.
LED4	Lights when DIMM_DDR2_2 slot is functional.	LED19	Lights when PCI_E3 slot is functional.
LED5	Lights when DIMM_DDR2_3 slot is functional.	LED20	Lights when PCI_E4 slot is functional.
LED6	Lights when DIMM_DDR2_4 slot is functional.	LED21	Lights when PCI1 slot is functional.
LED15	Lights when system is on standby mode.	LED22	Lights when PCI2 slot is functional.

LED 7, 8, 9 ,10, 11, 12, 13, 14

These four LEDs allow users to identify system problems through 16 various combinations of LED signals.



Red Green

LED Signal	Description	LED Signal	Description
Group4 Group3 Group2 Group1	System Power ON The D-LED will hang here if the processor is damaged or not installed properly.	Group4 Group3 Group2 Group1	Initializing Video Interface This will start detecting CPU clock, checking type of video onboard. Then, detect and initialize the video adapter.
Group4 Group3 Group2 Group1	Early Chipset Initialization	Group4 Group3 Group2 Group1	BIOS Sign On This will start showing information about logo, processor brand name, etc...
Group4 Group3 Group2 Group1	Memory Detection Test Testing onboard memory size. The D-LED will hang if the memory module is damaged or not installed properly.	Group4 Group3 Group2 Group1	Testing Base and Extended Memory Testing base memory from 240K to 640K and extended memory above 1MB using various patterns.
Group4 Group3 Group2 Group1	Decompressing BIOS image to RAM for fast booting.	Group4 Group3 Group2 Group1	Assign Resources to all ISA.
Group4 Group3 Group2 Group1	Initializing Keyboard Controller.	Group4 Group3 Group2 Group1	Initializing Hard Drive Controller This will initialize IDE drive and controller.
Group4 Group3 Group2 Group1	Testing VGA BIOS This will start writing VGA sign-on message to the screen.	Group4 Group3 Group2 Group1	Initializing Floppy Drive Controller This will initialize Floppy Drive and controller.
Group4 Group3 Group2 Group1	Processor Initialization This will show information regarding the processor (like brand name, system bus, etc...)	Group4 Group3 Group2 Group1	BootAttempt This will set low stack and boot via INT 19h.
Group4 Group3 Group2 Group1	Testing RTC (Real Time Clock)	Group4 Group3 Group2 Group1	Operating System Booting

Chapter 3
BIOS Setup

This chapter provides information on the BIOS Setup program and allows you to configure the system for optimum use.
You may need to run the Setup program when:

- An error message appears on the screen during the system booting up, and requests you to run SETUP.
- You want to change the default settings for customized features.

MSI
MICRO-STAR INTERNATIONAL

Entering Setup

Power on the computer and the system will start POST (Power On Self Test) process. When the message below appears on the screen, press <DEL> key to enter Setup.

Press DEL to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system by turning it OFF and On or pressing the RESET button. You may also restart the system by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys.

Important

1. *The items under each BIOS category described in this chapter are under continuous update for better system performance. Therefore, the description may be slightly different from the latest BIOS and should be held for reference only.*
2. *Upon boot-up, the 1st line appearing after the memory count is the BIOS version. It is usually in the format:*

A7345IMS V1.0 030807 where:

1st digit refers to BIOS maker as A = AMI, W = AWARD, and P = PHOENIX.
2nd - 5th digit refers to the model number.
6th digit refers to the chipset as I = Intel, N = nVidia, and V = VIA.
7th - 8th digit refers to the customer as MS = all standard customers.
V1.1 refers to the BIOS version.
030807 refers to the date this BIOS was released.

Control Keys

<↑>	Move to the previous item
<↓>	Move to the next item
<←>	Move to the item in the left hand
<→>	Move to the item in the right hand
<Enter>	Select the item
<Esc>	Jumps to the Exit menu or returns to the main menu from a submenu
<+/PU>	Increase the numeric value or make changes
<-/PD>	Decrease the numeric value or make changes
<F6>	Load Optimized Defaults
<F10>	Save all the CMOS changes and exit

Getting Help

After entering the Setup menu, the first menu you will see is the Main Menu.

Main Menu

The main menu lists the setup functions you can make changes to. You can use the arrow keys (↑↓) to select the item. The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Sub-Menu

If you find a right pointer symbol (as shown in the right view) appears to the left of certain fields that means a sub-menu can be launched from this field. A sub-menu contains additional options for a field parameter. You can use arrow keys (↑↓) to highlight the field and press <Enter> to call up the sub-menu. Then you can use the control keys to enter values and move from field to field within a sub-menu. If you want to return to the main menu, just press the <Esc >.

General Help <F1>

The BIOS setup program provides a General Help screen. You can call up this screen from any menu by simply pressing <F1>. The Help screen lists the appropriate keys to use and the possible selections for the highlighted item. Press <Esc> to exit the Help screen.

The Main Menu



▶ Standard CMOS Features
Use this menu for basic system configurations, such as time, date etc.

▶ Advanced BIOS Features
Use this menu to setup the items of AMI® special enhanced features.

▶ Integrated Peripherals
Use this menu to specify your settings for integrated peripherals.

▶ Power Management Setup
Use this menu to specify your settings for power management.

▶ PNP/PCI Configurations
This entry appears if your system supports PnP/PCI.

▶ H/W Monitor
This entry shows your PC health status.

▶ Cell Menu
Use this menu to specify your settings for frequency/voltage control and overclocking.

▶ Load Fail-Safe Defaults
Use this menu to load the default values set by the BIOS vendor for stable system performance.

▶ Load Optimized Defaults
Use this menu to load the default values set by the mainboard manufacturer specifically for optimal performance of the mainboard.

▶ BIOS Setting Password
Use this menu to set the password for BIOS.

▶ Save & Exit Setup
Save changes to CMOS and exit setup.

▶ Exit Without Saving
Abandon all changes and exit setup.

Standard CMOS Features

The items in Standard CMOS Features Menu includes some basic setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.


CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
Standard CMOS Features
Date (MM:DD:YY) : [Tue 01/01/2002]
Time (HH:MM:SS) : [00:03:54]
SATA1 [Not Detected]
SATA2 [Not Detected]
SATA3 [Hard Disk]
SATA4 [Not Detected]
SATA5 [Not Detected]
SATA6 [Not Detected]
Floppy A [1.44 MB]
System Information [Press Enter]
Help Item
Use [ENTER], [TAB] or [SHIFT-TAB] to select a field.
Use [+] or [-] to configure system Date.
↑↓↔:Move Enter:Select +/-/:Value F10:Save ESC:Exit F1:General Help
F6:Load Optimized Defaults

▶ Date (MM:DD:YY)

This allows you to set the system to the date that you want (usually the current date). The format is <day><month> <date> <year>.

day	Day of the week, from Sun to Sat, determined by BIOS. Read-only.
month	The month from Jan. through Dec.
date	The date from 1 to 31 can be keyed by numeric function keys.
year	The year can be adjusted by users.

▶ Time (HH:MM:SS)

This allows you to set the system time that you want (usually the current time). The time format is <hour> <minute> <second>.

▶ SATA1~6

Press <Enter> to enter the sub-menu, and the following screen appears.


CMOS Setup Utility - Copyright (C) 1905-2005, American Megatrends, Inc.
SATA3
SATA3
Help Item
Device :Hard Disk
Vendor :HDS72808OPLA380
Size :82.3GB
LBA/Large Mode [Auto]
DMA Mode [Auto]
Hard Disk S.M.A.R.T. [Auto]
Disabled: Disables LBA Mode.
Auto: Enables LBA Mode if the device supports it and the device is not already formatted with LBA Mode disabled.

▶ Device / Vender / Size
It will showing the device information that you connected to the SATA connector.

▶ LBA/Large Mode
This allows you to enable or disable the LBA Mode. Setting to Auto enables LBA mode if the device supports it and the devices is not already formatted with LBA mode disabled.

▶ DMA Mode
Select DMA Mode.

▶ Hard Disk S.M.A.R.T.
This allows you to activate the S.M.A.R.T. (Self-Monitoring Analysis & Reporting Technology) capability for the hard disks. S.M.A.R.T is a utility that monitors your disk status to predict hard disk failure. This gives you an opportunity to move data from a hard disk that is going to fail to a safe place before the hard disk becomes offline.

Important

Serial-ATA 1/2/3/4/5/6 Channel *are appearing when you connect the HD devices to the IDE/ SATA connector on the mainboard.*

▶ Floppy A
This item allows you to set the type of floppy drives installed. Available options: [None], [360K, 5.25 in.], [1.2M, 5.25 in.], [720K, 3.5 in.], [1.44M, 3.5 in.], [2.88M, 3.5 in.].

► System Information

Press <Enter> to enter the sub-menu, and the following screen appears.


CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
System Information
Intel(R) Core(TM)2 CPU 6300 @ 1.86GHz
CPU ID/MicroCode 06F5h/00h
CPU Frequency 1.86GHz (266x7)
BIOS Version V0.0B0 030807
Physical Memory 512MB
Usage Memory 512MB
Cache Size 2048 KB
Help Item
↑↓↔:Move Enter:Select +/-/:Value F10:Save ESC:Exit F1:General Help
F6:Load Optimized Defaults

This sub-menu shows the CPU information, BIOS version and memory status of your system (read only).

Advanced BIOS Features


CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
Advanced BIOS Features
Boot Sector Protection [Enabled]
Full Screen LOGO Display [Enabled]
Quick Booting [Enabled]
Boot Up Num-Lock LED [On]
IOAPIC Function [Enabled]
MPS Table Version [1 1]
CPU Feature [Press Enter]
Chipset Feature [Press Enter]
Boot Sequence [Press Enter]
Help Item
Enable/Disable Boot Sector Virus Protection.
↑↓↔:Move Enter:Select +/-/:Value F10:Save ESC:Exit F1:General Help
F6:Load Optimized Defaults

▶ Full Screen LOGO Display

This item enables you to show the company logo on the bootup screen. Settings are:

[Enabled] Shows a still image (logo) on the full screen at boot.
[Disabled] Shows the POST messages at boot.

▶ Quick Booting

Setting the item to [Enabled] allows the system to boot within 10 seconds since it will skip some check items.

▶ Boot Up Num-Lock LED

This setting is to set the Num Lock status when the system is powered on. Setting to [On] will turn on the Num Lock key when the system is powered on. Setting to [Off] will allow users to use the arrow keys on the numeric keypad.

▶ IOAPIC Function

This field is used to enable or disable the APIC (Advanced Programmable Interrupt Controller). Due to compliance with PC2001 design guide, the system is able to run in APIC mode. Enabling APIC mode will expand available IRQ resources for the system.

▶ MPS Table Version

This field allows you to select which MPS (Multi-Processor Specification) version to be used for the operating system. You need to select the MPS version supported by your operating system. To find out which version to use, consult the vendor of your operating system.

▶ CPU Feature

Press <Enter> to enter the sub-menu and the following screen appears:

CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
CPU Feature
Execute Bit Support [Disabled]
Set Limit CPUID MaxVal to 3 [Disabled]
Help Item

▶ Hyper-Threading Technology

This field appears only when the CPU supports Hyper-Threading. The processor uses Hyper-Threading technology to increase transaction rates and reduces end-user response times. The technology treats the two cores inside the processor as two logical processors that can execute instructions simultaneously. In this way, the system performance is highly improved. If you disable the function, the processor will use only one core to execute the instructions.

▶ Execute Bit Support

Intel's Execute Disable Bit functionality can prevent certain classes of malicious "buffer overflow" attacks when combined with a supporting operating system. This functionality allows the processor to classify areas in memory by where application code can execute and where it cannot. When a malicious worm attempts to insert code in the buffer, the processor disables code execution, preventing damage or worm propagation.

▶ Set Limit CPUID MaxVal to 3

The Max CPUID Value Limit is designed to limit the listed speed of the processor to older operating systems.

▶ Chipset Feature

Press <Enter> to enter the sub-menu and the following screen appears:

▶HPET

The HPET (High Precision Event Timers) is a component that is part of the chipset. You can to enable it, and will provide you with the means to get to it via the various ACPI methods.

▶ Boot Sequence

Press <Enter> to enter the sub-menu and the following screen appears:



▶ 1st/ 2nd/ 3rd Boot Device

The items allow you to set the first/ second/ third boot device where BIOS attempts to load the disk operating system.

▶ Boot From Other Device

Setting the option to [Yes] allows the system to try to boot from other device. if the system fails to boot from the 1st/ 2nd/ 3rd boot device.

Integrated Peripherals



▶ USB Controller
This setting allows you to enable/disable the onboard USB controller.

▶ USB Device Legacy Support
Select [Enabled] if you need to use a USB-interfaced device in the operating system.

▶ Onboard LAN Controller
This item is used to enable/disable the onboard LAN controller.

▶ LAN Option ROM
This item is used to decide whether to invoke the Boot ROM of the LAN controller.

▶ Onboard IEEE1394 Controller
This item allows you to enable/disable the onboard IEEE1394 controller.

▶ Extra IDE Controller
This item allows you to enable/disable the onboard IDE controller.

▶ HD Audio Controller
This setting is used to enable/disable the onboard audio controller.

▶ On-Chip ATA Devices
Press <Enter> to enter the sub-menu and the following screen appears:

▶ PCI IDE BusMaster
This item allows you to enable/ disable BIOS to used PCI busmastering for reading/ writing to IDE drives.

▶ Oc-Chip SATA Controller
These items allow users to enable or disable the SATA controller.

▶ RAID Mode
This item is used to enable/disable the RAID function for SATA devices.

▶ AHCI Devices Group
Press <Enter> to enter the AHCI settings sub-menu. The submenu displays the status of auto detection of IDE devices.

▶ AHCI Port0~5
Press <Enter> to enter the sub-menu. These submenu allow users to select the type of devices connected to the system.

▶ I/O Device Configuration
Press <Enter> to enter the sub-menu and the following screen appears:

▶ COM Port 1
Select an address and corresponding interrupt for the first serial port.

Power Management Setup


CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
Power Management Setup
ACPI Function [Enabled]
ACPI Standby State [S3]
Re-call VGA BIOS from S3 [Disabled]
Suspend Time Out(Minute) [Disabled]
Power Button Function [Power Off]
Restore on AC Power Loss [Off]
▶ Wake Up Event Setup [Press Enter]
Help Item
Select the ACPI state used for System Suspend.
↑↓↔:Move Enter:Select +/-/:Value F10:Save ESC:Exit F1:General Help
F6:Load Optimized Defaults

Important

S3-related functions described in this section are available only when your BIOS supports S3 sleep mode.

▶ ACPI Function

This item is to activate the ACPI (Advanced Configuration and Power Management Interface) Function. If your operating system is ACPI-aware, such as Windows 2000/ XP, select [Enabled].

▶ ACPI Standby State

This item specifies the power saving modes for ACPI function. If your operating system supports ACPI, such as Windows 2000/ XP , you can choose to enter the Standby mode in S1(POS) or S3(STR) fashion through the setting of this field. Settings are:

[S1] The S1 sleep mode is a low power state. In this state, no system context is lost (CPU or chipset) and hardware maintains all system context.

[S3] The S3 sleep mode is a lower power state where the in formation of system configuration and open applications/files is saved to main memory that remains powered while most other hardware components turn off to save energy. The information stored in memory will be used to restore the system when a “wake up” event occurs.

▶ Re-Call VGA BIOS From S3

When ***ACPI Standby State*** is set to [S3], users can select the options in this field. Selecting [Yes] allows BIOS to call VGABIOS to initialize the VGA card when system wakes up (resumes) from S3 sleep state. The system resume time is shortened when you disable the function, but system will need an VGA driver to initialize the VGA card. Therefore, if the VGA driver of the card does not support the initialization feature, the display may work abnormally or not function after resuming from S3.

▶ Suspend Time Out (Minute)

If system activity is not detected for the length of time specified in this field, all devices except CPU will be shut off.

▶ Power Button Function

This feature sets the function of the power button. Settings are:

[On/ Off]	The power button functions as normal power off button.
[Suspend]	When you press the power button, the computer enters the suspend/sleep mode, but if the button is pressed for more than four seconds, the computer is turned off.

▶ Restore On AC Power Loss

This item specifies whether your system will reboot after a power failure or interrupt occurs. Settings are:

[Off]	Always leaves the computer in the power off state.
[On]	Always leaves the computer in the power on state.
[Last State]	Restores the system to the status before power failure or interrupt occurred.

▶ Wakeup Event Setup

Press <Enter> and the following sub-menu appears.


CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
Wake Up Event Setup
Resume From S3 By USB Device [Disabled]
Resume From S3 By PS/2 Keyboard [Disabled]
Resume From S3 By PS/2 Mouse [Disabled]
Resume By PCI Device (PME#) [Enabled]
Resume By PCI-E Device [Enabled]
Resume By RTC Alarm [Enabled]
Date [15]
HH:MM:SS [12:30:30]
Help Item
Disable/Enable
PME to generate
a wake event.

▶ Resume From S3 By USB Device

The item allows the activity of the USB device to wake up the system from S3 (Suspend to RAM) sleep state.

▶ Resume From S3 By PS/2 Keyboard

This setting determines whether the system will be awakened from what power saving modes when input signal of the PS/2 keyboard is detected.

▶ Resume From S3 By PS/2 Mouse
This setting determines whether the system will be awakened from what power saving modes when input signal of the PS/2 mouse is detected.

▶ Resume by PCI Device (PME#)
When set to [Enabled], the feature allows your system to be awakened from the power saving modes through any event on PME (Power Management Event).

▶ Resume by PCI-E Device
When set to [Enabled], the feature allows your system to be awakened from the power saving modes through any event on PCIE device.

▶ Resume by RTC Alarm
The field is used to enable or disable the feature of booting up the system on a scheduled time/date.

PNP/PCI Configurations

This section describes configuring the PCI bus system and PnP (Plug & Play) feature. PCI, or **P**eripheral **C**omponent **I**nterconnect, is a system which allows I/O devices to operate at speeds nearing the speed the CPU itself uses when communicating with its special components. This section covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.


CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
PnP/PCI Configurations
Primary Graphic's Adapter [Internal]
PCI Latency Timer [64]
PCI Slot1 IRQ [Auto]
PCI Slot2 IRQ [Auto]
▸ IRQ Resource Setup [Press Enter]
Help Item
Select which graphics controller to use as the primary boot device
↑↓↔:Move Enter:Select +/-/:Value F10:Save ESC:Exit F1:General Help
F6:Load Uptimized Defaults

▶ Primary Graphic's Adapter
This setting specifies which graphics card is your primary graphics adapter.

▶ PCI Latency Timer
This item controls how long each PCI device can hold the bus before another takes over. When set to higher values, every PCI device can conduct transactions for a longer time and thus improve the effective PCI bandwidth. For better PCI performance, you should set the item to higher values.

▶ PCI Slot 1/ 2 IRQ
These items specify the IRQ line for each PCI slot.

► IRQ Resource Setup
Press <Enter> to enter the sub-menu and the following screen appears.



► IRQ 3/4/5/7/9/10/11/14/15
These items specify the bus where the specified IRQ line is used.
The settings determine if AMIBIOS should remove an IRQ from the pool of available IRQs passed to devices that are configurable by the system BIOS. The available IRQ pool is determined by reading the ESCD NVRAM. If more IRQs must be removed from the IRQ pool, the end user can use these settings to reserve the IRQ by assigning an [Reserved] setting to it. Onboard I/O is configured by AMIBIOS. All IRQs used by onboard I/O are configured as [Available]. If all IRQs are set to [Reserved], and IRQ 14/15 are allocated to the onboard PCI IDE, IRQ 9 will still be available for PCI and PnP devices.

Important

IRQ (Interrupt Request) lines are system resources allocated to I/O devices. When an I/O device needs to gain attention of the operating system, it signals this by causing an IRQ to occur. After receiving the signal, when the operating system is ready, the system will interrupt itself and perform the service required by the I/O device.

H/W Monitor


CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
H/W Monitor
Chassis Intrusion [Enabled]
CPU Smart Fan Target [40°C]
CPU Min.FAN speed(%) [62.5%]
SYS FAN1 Control [100%]
----- PC Health Status -----
CPU Temperature : 44°C/111°F
System Temperature : 30°C/86°F
CPU FAN Speed : 1529 RPM
SYS FAN1 Speed : 2092 RPM
SYS FAN2 Speed : 2369 RPM
CPU Vcore : 1.216 V
3.3V : 3.400 V
5V : 5.129 V
12V : 12.056 V
5V SB : 4.078 V
Help Item
Options
50%
75%
100%
↑↓↔:Move Enter:Select +/-/:Value F10:Save ESC:Exit F1:General Help
F6:Load Optimized Defaults

▶ Chassis Intrusion

The field enables or disables the feature of recording the chassis intrusion status and issuing a warning message if the chassis is once opened. To clear the warning message, set the field to [Reset]. The setting of the field will automatically return to [Enabled] later.

▶ CPU Smart FAN Target

The mainboard provides the Smart Fan function which can control the CPU fan speed automatically depending on the current temperature to keep it with in a specific range. You can select a fan target value here. If the current CPU fan temperature reaches to the target value, the smart fan function will be activated. It provides several sections to speed up for cooling down automaticlly .

▶ CPU Min.FAN speed(%)

This item allows users to select how percentage of minimum speed limit for the CPU fan.

▶ SYS FAN1 Control

This item allows users to select how percentage of speed for the SYS FAN1.

▶ PC Health Status

▶ CPU/ System Temperature, CPU FAN/ SYS FAN1/ SYS FAN2 Speed, CPU Vcore, 3.3V, 5V, 12V, 5V SB

These items display the current status of all of the monitored hardware devices/ components such as CPU voltage, temperatures and all fans' speeds.

Cell Menu


CMOS Setup Utility - Copyright (C) 1905-2005, American Megatrends, Inc.
Cell Menu
Current CPU Frequency 2.99GHz (333x9)
Current DRAM Frequency 800MHz
D.O.T Control [CPU and PCIE]
CPU D.O.T3 step1 setting [1%]
CPU D.O.T3 step2 setting [3%]
CPU D.O.T3 step3 setting [5%]
PCIE D.O.T3 step1 setting [1%]
PCIE D.O.T3 step2 setting [3%]
PCIE D.O.T3 step3 setting [5%]
Intel EIST [Enabled]
Adjust CPU FSB Frequency [333]
Adjust CPU Ratio [7]
Adjusted CPU Frequency [1867]
Advance DRAM Configuration [Press Enter]
FSB/Memory Ratio [Auto]
Adjusted DDR Memory Frequency [800]
PCIEx4 Speed Controller [Auto]
Adjust PCIE Frequency [100]
Auto Disable DIMM/PCI Frequency [Enabled]
CPU Voltage [+0.00V]
Memory Voltage [1.90]
VTT FSB Voltage [1.250]
NB Voltage [1.250]
SB I/O Power [1.5]
SB Core Power [1.05]
Spread Spectrum [Enabled]
Help Item
Options
Disabled
CPU Only
PCIE Only
CPU and PCIE
↑↓↔:Move Enter:Select +/-/:Value F10:Save ESC:Exit F1:General Help
F6:Load Optimized Defaults

Important

Change these settings only if you are familiar with the chipset.

► Current CPU / DRAM Frequency
These items show the current clocks of CPU and Memory speed. Read-only.

► D.O.T Control
This item allows users to select either/both of CPU and PCIE to be controlled under D. O.T. The D.O.T. (Dynamic Overclocking Technology) is an automatic overclocking function, included in the MSI™'s newly developed Dual CoreCell™ Technology. It is designed to detect the load balance of CPU and PCIE while running programs, and to adjust the best frequency automatically. When the motherboard detects system is

running programs, it will speed up automatically to make the program run smoothly and faster. When the system is temporarily suspending or staying in the low load balance, it will restore the default settings instead. Usually the Dynamic Overclocking Technology will be powered only when users' PC need to run huge amount of data like 3D games or the video process, and the CPU and PCIE frequency need to be boosted up to enhance the overall performance.

▶ CPU D.O.T3 step1/2/3 setting
Due to D.O.T can detect the CPU loading and increase the frequency with 3 overclocking steps. These items allow users to select the speed up range of each step.

▶ PCIE D.O.T3 step1/2/3 setting
Due to D.O.T can detect the PCIE loading and increase the frequency with 3 overclocking steps. These items allow users to select the speed up range of each step.

Important

Even though the Dynamic Overclocking Technology is more stable than manual overclocking, basically, it is still risky. We suggest user to make sure that your CPU can afford to overclocking regularly first. If you find the PC appears to be unstable or reboot incidentally, it's better to disable the Dynamic Overclocking or to lower the level of overclocking options. By the way, if you need to conduct overclocking manually, you also need to disable the Dynamic OverClocking first.

▶ Intel EIST
The Enhanced Intel SpeedStep technology allows you to set the performance level of the microprocessor whether the computer is running on battery or AC power. This field will appear after you installed the CPU which support speedstep technology.

▶ Adjust CPU FSB Frequency
This item allows you to set the CPU FSB frequency (in MHz).

▶ Adjust CPU Ratio
This field appears only when the CPU supports this function. It is adjustable only when **Intel EIST** set to Disable. This item allows you to set the CPU ratio.

▶ Adjusted CPU Frequency
It shows the adjusted CPU frequency (FSB x Ratio). Read-only.

▶ Advance DRAM Configuration
Press <Enter> to enter the sub-menu and the following screen appears.


CMOS Setup Utility - Copyright (C) 1985-2005, American Megatrends, Inc.
Advance DRAM Configuration
Configure DRAM Timing by SPD [Disabled]
DRAM CAS# Latency [5]
DRAM RAS# to CAS# Delay [6 DRAM Clocks]
DRAM RAS# Precharge [6 DRAM Clocks]
DRAM RAS# Activate to Precha [15 DRAM Clocks]
DRAM TRFC [38 DRAM Clocks]
DRAM TWR [12 DRAM Clocks]
DRAM TWTR [12 DRAM Clocks]
DRAM TRRD [12 DRAM Clocks]
DRAM TRTP [12 DRAM Clocks]
Help Item
Options
Enabled
Disabled

▶ Configuration DRAM Timing by SPD
Setting to [Enabled] enables DRAM CAS# Latency automatically to be determined by BIOS based on the configurations on the SPD (Serial Presence Detect) EEPROM on the DRAM module.

▶ DRAM CAS# Latency
When the **Configuration DRAM Timing by SPD** sets to [Disabled], the field is adjustable.This controls the CAS latency, which determines the timing delay (in clock cycles) before SDRAM starts a read command after receiving it.

▶ DRAM RAS# to CAS# Delay
When the **Configuration DRAM Timing by SPD** sets to [Disabled], the field is adjustable. When DRAM is refreshed, both rows and columns are addressed separately. This setup item allows you to determine the timing of the transition from RAS (row address strobe) to CAS (column address strobe). The less the clock cycles, the faster the DRAM performance.

▶ DRAM RAS# Precharge
When the **Configuration DRAM Timing by SPD** sets to [Disabled], this field is adjustable. This setting controls the number of cycles for Row Address Strobe (RAS) to be allowed to precharge. If insufficient time is allowed for the RAS to accumulate its charge before DRAM refresh, refresh may be incomplete and DRAM may fail to retain data. This item applies only when synchronous DRAM is installed in the system.

▶ DRAM TRFC
When the **Configuration DRAM Timing by SPD** sets to [Disabled], the field is adjustable. This setting determines the time RFC takes to read from and write to a memory cell.

▶ DRAM TWR
When the **Configuration DRAM Timing by SPD** sets to [Disabled], the field is adjustable. Minimum time interval between end of write data burst and the start of a precharge command. Allows sense amplifiers to restore data to cells.

▶ DRAM TWTR
When the **Configuration DRAM Timing by SPD** sets to [Disabled], the field is adjustable. Minimum time interval between the end of write data burst and the

start of a column-read command. It allows I/O gating to overdrive sense amplifiers before read command starts.

▶ DRAM TRRD
When the **Configuration DRAM Timing by SPD** sets to [Disabled], the field is adjustable. Specifies the active-to-active delay of different banks. Time interval between a read and a precharge command.

▶ DRAM TRTP
When the **Configuration DRAM Timing by SPD** sets to [Disabled], the field is adjustable. Time interval between a read and a precharge command.

▶ FSB/Memory Ratio
This item will allow you to adjust the FSB/Ratio of the memory.

▶ Adjusted DDR Memory Frequency
It shows the adjusted DDR Memory frequency. Read-only.

▶ PCIEx4 Speed Controller
This item will allow you to select the PCIEx4 speed.Settings are:

[Auto]	The output speed depends on the device installed on PCIEx4 slot.
[4X]	The output speed keeps on 4X. In this mode, PCI_E2 and PCI_E3 are not able to function.
[2X]	The output speed keeps on 2X. In this mode, you may use PCI_E2, PCI_E3 and PCI_E4 simultaneously, please note that the output speed on PCI_E4 in only with 2X.

▶ Adjust PCIE Frequency
This field allows you to select the PCIE frequency (in MHz).

▶ Auto Disable DIMM/PCI Frequency
When set to [Enabled], the system will remove (turn off) clocks from empty DIMM and PCI slots to minimize the electromagnetic interference (EMI).

▶ CPU Voltage / Momory Voltage / VTT FSB Voltage / NB Voltage / SB I/O Power / SB Core Power
These items dispaly the power status of CPU, Memory, FSB and chipset. Read-only.

▶ Spread Spectrum
When the motherboard's clock generator pulses, the extreme values (spikes) of the pulses create EMI (Electromagnetic Interference). The Spread Spectrum function reduces the EMI generated by modulating the pulses so that the spikes of the pulses are reduced to flatter curves. If you do not have any EMI problem, leave the setting at Disabled for optimal system stability and performance. But if you are plagued by EMI, set to Enabled for EMI reduction. Remember to disable Spread Spectrum if you are overclocking because even a slight jitter can introduce a temporary boost in clock speed which may just cause your overclocked processor to lock up.

Important

1. *If you do not have any EMI problem, leave the setting at [Disabled] for optimal system stability and performance. But if you are plagued by EMI, select the value of Spread Spectrum for EMI reduction.*
2. *The greater the Spread Spectrum value is, the greater the EMI is reduced, and the system will become less stable. For the most suitable Spread Spectrum value, please consult your local EMI regulation.*
3. *Remember to disable Spread Spectrum if you are overclocking because even a slight jitter can introduce a temporary boost in clock speed which may just cause your overclocked processor to lock up.*

CPU and Memory Clock Overclocking

The **D.O.T Control, Adjust CPU FSB Frequency, Adjust CPU Ratio, FSB/Memory Ratio** are the items for you to overclock the CPU and the Memory. Please refer to the descriptions of these fields for more information.

Important

1. *CPU Speed = CPU Frequency * CPU Ratio*
2. *This motherboard supports overclocking greatly. However, please make sure your peripherals and components are bearable for some special settings. Any operation that exceeds product specification is not recommended. Any risk or damge resulting from improper operation will not be under our product warranty.*

Two ways to save your system from failed overclocking...

Reboot

1. Press the Power button to reboot the system three times. Please note that, to avoid electric current to affect other devices or components, we suggest an interval of more than 10 seconds among the reboot actions.

2. At the fourth reboot, BIOS will determine that the previous overclocking is failed and restore the default settings automatically. Please press any key to boot the system normally when the following message appears on screen.

```
Warning !!! The previous performance of overclocking is failed,
and the system is restored to the defaults setting,
Press any key exclude "DEL" to enter SETUP.....
```

Clear CMOS

- Please refer to “chapter 2” for more information about how to clear CMOS data.

Load Fail-Safe/ Optimized Defaults

The two options on the main menu allow users to restore all of the BIOS settings to the default Fail-Safe or Optimized values. The Optimized Defaults are the default values set by the mainboard manufacturer specifically for optimal performance of the mainboard. The Fail-Safe Defaults are the default values set by the BIOS vendor for stable system performance.

When you select Load Fail-Safe Defaults, a message as below appears:

Pressing *Y* loads the BIOS default values for the most stable, minimal system performance.

When you select Load Optimized Defaults, a message as below appears:



Pressing *Y* loads the default factory settings for optimal system performance.

BIOS Setting Password

When you select this function, a message as below will appear on the screen:

Type the password, up to six characters in length, and press <Enter>. The password typed now will replace any previously set password from CMOS memory. You will be prompted to confirm the password. Retype the password and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To clear a set password, just press <Enter> when you are prompted to enter the password. A message will show up confirming the password will be disabled. Once the password is disabled, the system will boot and you can enter Setup without entering any password.

When a password has been set, you will be prompted to enter it every time you try to enter Setup. This prevents an unauthorized person from changing any part of your system configuration.

Appendix A
Realtek ALC888/888T Audio

The Realtek ALC888/888T provides 10-channel DAC that simultaneously supports 7.1 sound playback and 2 channels of independent stereo sound output (multiple streaming) through the Front-Out-Left and Front-Out-Right channels.

MSI
MICRO-STAR INTERNATIONAL

Installing the Realtek HD Audio Driver

You need to install the driver for Realtek ALC888/888T codec to function properly before you can get access to 2-, 4-, 6-, 8- channel or 7.1+2 channel audio operations. Follow the procedures described below to install the drivers for different operating systems.

Installation for Windows 2000/XP

For Windows® 2000, you must install Windows® 2000 Service Pack4 or later before installing the driver. For Windows® XP, you must install Windows® XP Service Pack1 or later before installing the driver.

The following illustrations are based on Windows® XP environment and could look slightly different if you install the drivers in different operating systems.

1. Insert the application CD into the CD-ROM drive. The setup screen will automatically appear.
2. Click **Realtek HD Audio Driver**.

Important

*The **HD Audio Configuration** software utility is under continuous update to enhance audio applications. Hence, the program screens shown here in this section may be slightly different from the latest software utility and shall be held for reference only.*

3. Click **Next** to install the Realtek High Definition Audio Driver.


Realtek High Definition Audio Driver Setup (1.73)
Welcome to the InstallShield Wizard for Realtek High Definition Audio Driver
The InstallShield® Wizard will install Realtek High Definition Audio Driver on your computer. To continue, click Next.
< Back
Next >
Cancel
Click here

4. Click **Finish** to restart the system.


Realtek High Definition Audio Driver Setup (1.73)
Maintenance Complete
InstallShield Wizard has finished performing maintenance operations on Realtek High Definition Audio Driver.
Yes, I want to restart my computer now.
No, I will restart my computer later.
Remove any disks from their drives, and then click Finish to complete setup.
< Back
Finish
Cancel
Select this option
Click here

Software Configuration

After installing the audio driver, you are able to use the 2-, 4-, 6- or 8- channel audio feature now. Click the audio icon from the system tray at the lower-right corner of the screen to activate the **HD Audio Configuration**. It is also available to enable the audio driver by clicking the **Realtek HD Audio Manager** from the **Control Panel**.



Sound Effect

Here you can select a sound effect you like from the **Environment** list.

Environment Simulation

You will be able to enjoy different sound experience by pulling down the arrow, totally 23 kinds of sound effect will be shown for selection. Realtek HD Audio Sound Manager also provides five popular settings “Stone Corridor”, “Bathroom”, “Sewer pipe”, “Arena” and “Audio Corridor” for quick enjoyment.

You may choose the provided sound effects, and the equalizer will adjust automatically. If you like, you may also load an equalizer setting or make an new equalizer setting to save as an new one by using the “**Load EQ Setting**” and “**Save Preset**” button, click “**Reset EQ Setting**” button to use the default value, or click “**Delete EQ Setting**” button to remove a preset EQ setting.

There are also other pre-set equalizer models for you to choose by clicking “**Others**” under the **Equalizer** part.

Equalizer Selection

Equalizer frees users from default settings; users may create their owned preferred settings by utilizing this tool.

10 bands of equalizer, ranging from 100Hz to 16KHz.



Save
The settings are saved permanently for future use

Reset
10 bands of equalizer would go back to the default setting

Enable / Disable
To disable, you can temporarily stop the sound effect without losing the settings

Load
Whenever you would like to use preload settings, simply click this, the whole list will be shown for your selection.

Delete
To delete the pre-saved settings which are created from previous steps.

Frequently Used Equalizer Setting

Realtek recognizes the needs that you might have. By leveraging our long experience at audio field, Realtek HD Audio Sound Manager provides you certain optimized equalizer settings that are frequently used for your quick enjoyment.

[How to Use It]

Other than the buttons “Pop” “Live” “Club” & “Rock” shown on the page, to pull down the arrow in “Others”, you will find more optimized settings available to you.

Karaoke Mode

Karaoke mode brings Karaoke fun back home. Simply using the music you usually play, Karaoke mode can help you eliminate the vocal of the song or adjust the key to accommodate your range.

1.Vocal Cancellation: Single click on “Voice Cancellation”, the vocal of the song would be eliminated, while the background music is still in place, and you can be that singer!

2.Key Adjustment: Using “Up / Down Arrow” to find a key which better fits your vocal range.



Mixer

In the **Mixer** part, you may adjust the volumes of the rear and front panels individually.

1. Adjust Volume

You can adjust the volume of the speakers that you pluged in front or rear panel by select the **Realtek HD Audio rear output** or **Realtek HD Audio front output** items.

Important

*Before set up, please make sure the playback devices are well plugged in the jacks on the rear or front panel. The **Realtek HD Audio front output** item will appear after you pluging the speakers into the jacks on the front panel.*

2. Multi-Stream Function

ALC888 supports an outstanding feature called Multi-Stream, which means you may play different audio sources simultaneously and let them output respectively from the indicated real panel or front panel. This feature is very helpful when 2 people are using the same computer together for different purposes.

Click the button and the Mixer **ToolBox** menu will appear. Then check the **Enable playback multi-streaming** and click **OK** to save the setup.

Important

You have to plug audio device into the jacks on the rear and front panel first before enable the multi-stream function.



When you are playing the first audio source (for example: use Windows Media Player to play DVD/VCD), the output will be played from the rear panel, which is the default setting.

Then you **must** to select the **Realtek HD Audio front output** from the scroll list **first**, and use a different program to play the second audio source (for example: use Winamp to play MP3 files). You will find that the second audio source (MP3 music) will come out from the Line-Out audio jack of Front Panel.

3. Playback control



Mute
You may choose to mute single or multiple volume controls or to completely mute sound output.

Tool
- Show the following volume controls
This is to let you freely decide which volume control items to be displayed.
- Advanced controls
- Enable playback multi-streaming
With this function, you will be able to have an audio chat with your friends via headphone (stream 1 from front panel) while still have music (stream 2 from back panel) in play. At any given period, you can have maximum 2 streams operating simultaneously.



4. Recording control

Mute
You may choose to mute single or multiple volume controls or to completely mute sound input.
Tool
- Show the following volume controls
This is to let you freely decide which volume control items to be displayed.
- Enable recording multi-streaming



Important

ALC888 allows you to record the CD, Line, Mic and Stereo Mix channels simultaneously, frees you from mixing efforts. At any given period, you may choose 1 of the following 4 channels to record.

Audio I/O

In this tab, you can easily configure your multi-channel audio function and speakers. You can choose a desired multi-channel operation here.

a. **Headphone** for the common headphone
b. **2CH Speaker** for Stereo-Speaker Output
c. **4CH Speaker** for 4-Speaker Output
d. **6CH Speaker** for 5.1-Speaker Output
e. **8CH Speaker** for 7.1-Speaker Output

Speaker Configuration:

1. Plug the speakers in the corresponding jack.

2. Dialogue “connected device” will pop up for your selection. Please select the device you have plugged in.
   - If the device is being plugged into the correct jack, you will be able to find the icon beside the jack changed to the one that is same as your device.
   - If not correct, Realtek HD Audio Manager will guide you to plug the device into the correct jack.

Connector Settings

Click to access connector settings.

Connector Settings
Connector Settings
Disable front panel jack detection
Mute rear panel output when front headphone plugged in.
Enable auto popup dialog, when device has been plugged in
OK
Cancel

Disable front panel jack detection (option)
Find no function on front panel jacks? Please check if front jacks on your system are so-called AC'97 jacks. If so, please check this item to disable front panel jack detection.

Mute rear panel output when front headphone plugged in.

Enable auto popup dialogue, when device has been plugged in
Once this item checked, the dialog "Connected device" would automatically pop up when device plugged in.

S/PDIF

Short for Sony/Philips Digital Interface, a standard audio file transfer format. S/PDIF allows the transfer of digital audio signals from one device to another without having to be converted first to an analog format. Maintaining the viability of a digital signal prevents the quality of the signal from degrading when it is converted to analog.



Output Sampling Rate

44.1KHz: This is recommend while playing CD.
48KHz: This is recommended while playing DVD or Dolby.
96KHz: This is recommended while playing DVD-Audio.
192KHz: This is recommended while playing High quality Audio.

Output Source

Output digital audio source: The digital audio format (such as .wav, .mp3,.midi etc) will come out through S/PDIF-Out.
S/PDIF-in to S/PDIF -out pass though mode: The data from S/PDIF-In can be real-time played from S/PDIF-Out.

Test Speakers

You can select the speaker by clicking it to test its functionality. The one you select will light up and make testing sound. If any speaker fails to make sound, then check whether the cable is inserted firmly to the connector or replace the bad speakers with good ones. Or you may click the **auto test** button to test the sounds of each speaker automatically.



Microphone

In this tab you may set the function of the microphone. Select the **Noise Suppression** to remove the possible noise during recording, or select **Acoustic Echo Cancellation** to cancel the acoustic echo druing recording.

Acoustic Echo Cancellation prevents playback sound from being recorded by microphone together with your sound. For example, you might have chance to use VOIP function through Internet with your friends. The voice of your friend will come out from speakers (playback). However, the voice of your friend might also be recorded into your microphone then go back to your friend through Internet. In that case, your friend will hear his/her own voice again. With AEC(Acoustic Echo Cancellation) enabled at your side, your friend can enjoy the benefit with less echo.

3D Audio Demo

In this tab you may adjust your 3D positional audio before playing 3D audio applications like gaming. You may also select different environment to choose the most suitable environment you like.

Information

In this tab it provides some information about this HD Audio Configuration utility, including Audio Driver Version, DirectX Version, Audio Controller & Audio Codec. You may also select the language of this utility by choosing from the **Language** list.

Also there is a selection **Show icon in system tray**. Switch it on and an icon will show in the system tray. Right-click on the icon and the **Audio Accessories** dialogue box will appear which provides several multimedia features for you to take advantage of.

Hardware Setup

Connecting the Speakers

When you have set the Multi-Channel Audio Function mode properly in the software utility, connect your speakers to the correct phone jacks in accordance with the setting in software utility.

n 2-Channel Mode for Stereo-Speaker Output

Refer to the following diagram and caption for the function of each phone jack on the back panel when 2-Channel Mode is selected.



1 Line In
2 Line Out *(Front channels)*
3 MIC
4 No function
5 No function
6 No function

n 4-Channel Mode for 4-Speaker Output



4-Channel Analog Audio Output

1. Line In
2. Line Out *(Front channels)*
3. MIC
4. Line Out *(Rear channels)*
5. No function
6. No function

n 6-Channel Mode for 6-Speaker Output



6-Channel Analog Audio Output

1. Line In
2. Line Out *(Front channels)*
3. MIC
4. Line Out *(Rear channels)*
5. Line Out *(Center and Subwoofer channel)*
6. No function

n 8-Channel Mode for 8-Speaker Output



8-Channel Analog Audio Output

1. Line In
2. Line Out *(Front channels)*
3. MIC
4. Line Out *(Rear channels)*
5. Line Out *(Center and Subwoofer channel)*
6. Line Out *(Side channels)*

Important

To enable 7.1 channel audio-out function on Vista operating system, you have to install the Realtek Audio Driver. Or, the mainboard will support 5.1 channel audio-out only.

Appendix B
Dual Core Center

Dual CoreCenter, the most useful and powerful utility that MSI has spent much research and efforts to develop, helps users to monitor or configure the hardware status of MSI Mainboard & MSI Graphics card in windows, such as CPU/GPU clock, voltage, fan speed and temperature.
Before you install the Dual CoreCenter, please make sure the system has meet the following requirements:

1. Intel Pentium4 / Celeron, AMD Athlon XP/ Sempron or compatible CPU with PCI Express slot.
2. 256MB system memory.
3. CD-ROM drive for software installation.
4. Operation system: Windows XP.
5. DotNet Frame Work 2.0

MSI
MICRO-STAR INTERNATIONAL

Activating Dual Core Center

Once you have your Dual Core Center installed (locate the setup source file in the setup CD accompanying with your mainboard, path: **Utility --> MSI Utility --> Dual Core Center**), it will have an icon in the system tray, a short cut icon on the desktop, and a short cut path in your "Start-up" menu. You may double-click on each icon to enable Dual Core Center.

short-cut icon in the system tray



short-cut path in the start-up menu (path: Start-->Programs-->MSI--> DualCoreCenter-->DualCoreCenter)

Main

Before using this utility, we have to remind you: only when installing the MSI V044 (V044 has to install with the version 8.26 or newer driver)/ V046 or V060 graphics card can activate the full function of this utility. If you install a graphics card of other brand, only hardware status of the MSI mainboard would be available.

Introduction:

Click each button appearing above to enter sub-menu to make further configuration or to execute the function.

MB

Click MB button to read current CPU temperature, FSB and CPU clock of mainboard will show below.

VGA

Click VGA button to read current GPU temperature, GPU clock and memory clock of graphics card will show below.

DOT

Click DOT button to enable or disable the Dynamic Overclocking Technology.

AV/ Game/ Office/ Silence/ Cool

MSI provides five common settings for different environments. The settings had been set to optimal values to reach better performance in each environment. Click the button you need.

Important

Before clicking the AV/ Game/ Office/ Silence or Cool button, select Smooth mode or Sharp mode to decide whether you want the system to reach the optimal values smoothly or quickly.

Sharp mode ***Smooth mode***

Clock

In this sub-menu, you can adjust and monitor the clocks of MB and graphics card.

Voltage

In this sub-menu, you can adjust and monitor the voltages of MB and graphics card.

FAN Speed

In this sub-menu, you can adjust and monitor the fan speeds of MB and graphics card.

Temperature

In this sub-menu, you can monitor the temperatures of MB and graphics card.

User Profile

In this sub-menu, you can set the values of clock, voltage and fan speed by your need and save them in a profile. You can save 3 profiles for further use.

Important

Click on the icon , the clock, voltage, fan, and temperature buttons will appear beside the icon.



DOT (Dynamic OverClocking)

Dynamic Overclocking Technology is an automatic overclocking function, included in the MSI™'s newly developed Dual CoreCenter Technology. It is designed to detect the loading of CPU/ GPU while running programs, and to over-clock automatically. When the motherboard detects that the loading of CPU is exceed the default threshold for a time, it will speed up the CPU and fan automatically to make the system run smoother and faster. When the graphics card detects that the loading of GPU is exceed the default threshold for a time, it will speed up the GPU, memory, fan and voltage automatically to make the system run smoother and faster. When the CPU/ GPU is temporarily suspending or staying in low loading balance, it will restore the default settings instead. Usually the Dynamic Overclocking Technology will be powered only when users' PC runs huge amount of data, like 3D games or video process, and the motherboard/ graphicd card need to be boosted up to enhance the overall performance. There will be several selections when you click the DOT rate button (include increase rate and decrease rate buttons), to select the DOT level, then you have to click the DOT button to apply the DOT function.



DOT FSB-UP Rate button



DOT FSB-DOWN Rate button

Important

Even though the Dynamic Overclocking Technology is more stable than manual overclocking, basically, it is still risky. We suggest user to make sure that your CPU can afford to overclock regularly first. If you find the PC appears to be unstable or reboot incidentally, it's better to lower the level of overclocking options. By the way, if you need to conduct overclocking manually, please do not to apply the DOT function.

Clock

In the **Clock** sub-menu, you can see clock status (including FSB/ CPU clock of mainboard and GPU/ memory clock of graphics card) of your system. And you can select desired value for overclocking. There will be several items for you to select for overclocking after you click button. You can click the plus sign button to increase the clock, or click the minus sign button to decrease the clock. And finally, click the Apply button to apply the values adjusted. If you do not want to apply the adjustments, click the Cancel button to cancel. Or click the Default button to restore the default values.

On the underside, it shows the graphs of the clocks. Only the curves of the item which the button is lit up with red color will be shown.

Important

*In the user profile, clicking the **Save** button can save the changes to it. In the default profile, the Save button is not available.*

Voltage

In the **Voltage** sub-menu, you can see voltage status (including Vcore, memory, GPU voltage... etc.) of your system, and you can select desired value for overclocking. It will show several items to select for overclocking after you click the button. You can click the plus sign button to increase the voltage, or click the minus sign button to decrease. And finally, click the Apply button to apply the adjustments. If you do not want to apply the adjustments, click the Cancel button to cancel. Or click the Default button to restore the default values.

On the underside, it shows the graphs of the voltages. Only the curves of the item which the button is lit up with red color will be shown.

Important

*In the user profile, clicking the **Save** button can save the changes to it. In the default profile, the Save button is not available.*

FAN Speed

In the **FAN Speed** sub-menu, you can read fan status of your system. Select higher speed for better cooling effect. There are several sections for you to change the fan speed to a section after clicking button. Click the plus sign button to increase the fan speed to a section, or click the minus sign button to decrease. Or click the Default button to restore the default values.

On the underside, it shows the graphs of the fan speed. Only the curves of the item which the button is lit up with red color will be shown.

Important

1. *When you set the fan speed manually, please make sure to disabled the "CPU Smart FAN Target" item in the BIOS.*
2. *In the user profile, clicking the* ***Save*** *button can save the changes to it. In the default profile, the Save button is not available.*

Temperature

In the **Temperature** sub-menu, you can see temperature status of your system.



On the underside, it shows the graphs of the temperatures. Only the curves of the item which the button is lit up with red color will be shown.

User Profile

In the **User Profile** sub-menu, click the setting button that besides the user profile bar, and the next screen will appear.

Here you can define the clock/ fan speed/ voltage by your need, click the button to choose a value quickly, or click the plus / minus sign button to increase/ decrease the value.



Use the draw bar to set the max system temperature. When the system temperature exceeds the threshold you defined, the system will pop up a warning message and shut down the system.
Use the draw bar to set the minimal fan speed. When the fan speed is lower than the threshold you defined, the system will pop up a warning message.

After setting all values you need, you can change the user profile name in the box then click the save button to save all changes in a profile.



Finally, you can choose the user profile by click the button in the left side and click the Apply button to load the user profile.



Appendix C
Intel ICH9R SATA RAID

This appendix will assist users in configuring and enabling RAID functionality on platforms
The ICH9R RAID solution supports RAID level 0 (striping), RAID level 1 (mirroring), RAID level 5 (striping with parity) and RAID level 10 (striping and mirroring).

MSI
MICRO-STAR INTERNATIONAL

ICH9R Introduction

The ICH9R provides a hybrid solution that combines 6 independent SATAII ports for support of up to 6 Serial ATAII (Serial ATAII RAID) drives.

Serial ATAII (SATAII) is the latest generation of the ATA interface. SATA hard drives deliver blistering transfer speeds up to 300MB/sec. Serial ATA uses long, thin cables, making it easier to connect your drive and improving the airflow inside your PC. The most outstanding features are:

1. Supports 300MB/s transfers with CRC error checking.
2. Supports Hot-plug-n-play feature.
3. Data handling optimizations including tagged command queuing, elevator seek and packet chain command.

Intel® ICH9R offers RAID level 0 (Striping), RAID level 1 (Mirroring and Duplexing), RAID level 5 (Block Interleaved Distributed Parity), RAID level 10 (A Stripe of Mirrors) and Intel® Martix Storage Technology.

RAID 0 breaks the data into blocks which are written to separate hard drives. Spreading the hard drive I/O load across independent channels greatly improves I/O performance. RAID 1 provides data redundancy by mirroring data between the hard drives and provides enhanced read performance. RAID 5 Provides data striping at the byte level and also stripe error correction information. This results in excellent performance and good fault tolerance. Level 5 is one of the most popular implementations of RAID. RAID 10 Not one of the original RAID levels, multiple RAID 1 mirrors are created, and a RAID 0 stripe is created over these. Intel Matrix RAID Technology is the advanced ability for two RAID volumes to share the combined space of two hard drives being used in unison.

Important

The least number of hard drives for RAID 0, RAID 1 or Matrix mode is 2. The least number of hard drives for RAID 10 mode is 4. And the least number of hard drives for RAID 5 mode is 3.
All the information/ volumes/ pictures listed in your system might differ from the illustrations in this appendix.

BIOS Configuration

The Intel Matrix Storage Manager Option ROM should be integrated with the system BIOS on all motherboards with a supported Intel chipset. The Intel Matrix Stroage Manager Option ROM is the Intel RAID implementation and provides BIOS and DOS disk services. Please use <Ctrl> + <I> keys to enter the "Intel(R) RAID for Serial ATA" status screen, which should appear early in system boot-up, during the POST (Power-On Self Test). Also, you need to enable the RAID function in BIOS to create, delete and reset RAID volumes.

Using the Intel Matrix Stroage Manager Option ROM

1. Creating, Deleting and Resetting RAID Volumes:

The Serial ATA RAID volume may be configured using the RAID Configuration utility stored within the Intel RAID Option ROM. During the Power-On Self Test (POST), the following message will appear for a few seconds:

Important

The "Driver Model", "Serial #" and "Size" in the following example might be different from your system.


Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation, All Rights Reserved.'
RAID Volumes
None defined.
Physical Disks::
Port Device Model Serial # Size Type/Status(Vol ID)
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB Non-RAID Disk
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB Non-RAID Disk
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Non-RAID Disk
3 HDS722580VLSA80 VNRB3EC20579SL 76.7GB Non-RAID Disk
Press <CTRL-I> to enter Configuration Utility..

After the above message shows, press <Ctrl> and <I> keys simultaneously to enter the RAID Configuration Utility.

Important

The following procedure is only available with a newly-built system or if you are reinstalling your OS. It should not be used to migrate an existing system to RAID.

After pressing the <Ctrl> and <I> keys simultaneously, the following window will appear:


Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation. All Rights Reserved.
[MAIN MENU]
1. Create RAID Volume
2. Delete RAID Volume
3. Reset Disks to Non-RAID
4. Exit
[DISK/VOLUME INFORMATION]
RAID Volumes:
None defined.
Physical Disks:
Port Device Model Serial # Size Type/Status(Vol ID)
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB Non-RAID Disk
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB Non-RAID Disk
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Non-RAID Disk
3 HDS722580VLSA80 VNRB3EC20579SL 76.7GB Non-RAID Disk
[↑ ↓]Change [ESC]-Previous Menu [ENTER]-Select

(1) Create RAID Volume

1. Select option 1 “Create RAID Volume” and press <Enter> key. The following screen appears. Then in the **Name** field, specify a RAID Volume name and then press the <TAB> or <Enter> key to go to the next field.
2. Use the arrow keys to select the RAID level best suited to your usage model in **RAID Level**.


Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation. All Rights Reserved.
[CREATE VOLUME MENU]
Name: Volume0
RAID Level: RAID5(Parity)
Disks: Select Disks
Strip Size: 64KB
Capacity: 228.0 GB
Create Volume
[HELP]
Choose the RAID level:
RAID0 - Stripes data (performance).
RAID1 - Mirrors data (redundancy).
RAID10 - Mirrors data and stripes the mirror.
RAID5 - Stripes data and parity.
[↑ ↓]Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select

3. In the **Disk** field, press <Enter> key and the following screen appears. Use <Space> key to select the disks you want to create for the RAID volume, then click <Enter> key to finish selection.


Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation. All Rights Reserved.
[CREATE VOLUME MENU]
Name: Volume0
RAID Level: RAID5(Parity)
[SELECT DISKS]
Port Drive Model Serial # Size Status
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB Non-RAID Disk
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB Non-RAID Disk
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Non-RAID Disk
3 HDS722580VLSA80 VNRB3EC20579SL 76.7GB Non-RAID Disk
Select 3 to 4 disks to use in creating the volume.
[↑ ↓]-Previous/Next [SPACE]-Selects [ENTER]-Selection Complete
[↑ ↓]Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select

4. Then select the strip value for the RAID array by using the “upper arrow” or “down arrow” keys to scroll through the available values, and pressing the <Enter> key to select and advance to the next field. The available values range from 4KB to 128 KB in power of 2 increments. The strip value should be chosen based on the planned drive usage. Here are some typical values:
   RAID0 – 128KB
   RAID10 – 64KB
   RAID5 – 64KB
5. Then select the capacity of the volume in the **Capacity** field. The default value is the maximum volume capacity of the selected disks.


Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation. All Rights Reserved.
[CREATE VOLUME MENU]
Name: Volume0
RAID Level: RAID5(Parity)
Disks: Select Disks
Strip Size: 64KB
Capacity: 228.0 GB
Create Volume
[HELP]
Enter the volume capacity. The default value indicates the maximum volume capacity using the selected disks. If less than the maximum capacity is chosen, creation of a second volume is needed to utilize the remaining space.
[↑ ↓]Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select

Important

Since you want to create two volumes (Intel Matrix RAID Technology), this default size (maximum) needs to be reduced. Type in a new size for the first volume. As an example: if you want the first volume to span the first half of the two disks, re-type the size to be half of what is shown by default. The second volume, when created, will automatically span the remainder of two hard drives.

6. Then the following screen appears for you to confirm if you are sure to create the RAID volume. Press <Y> to continue.

Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation. All Rights Reserved.
[CREATE VOLUME MENU]
Name: Volume0
RAID Level: RAID5(Parity)
Disks: Select Disks
Strip Size: 64KB
Capacity: 228.0 GB
WARNING: ALL DATA ON SELECTED DISKS WILL BE LOST
Are you sure you want to create this volume? (Y/N):
Press ENTER to Create the specified volume.
[↑ ↓]Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select

7. Then the following screen appears to indicate that the creation is finished.


Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation. All Rights Reserved.
[MAIN MENU]
1. Create RAID Volume
2. Delete RAID Volume
3. Reset Disk to Non-RAID
4. Exit
[DISK/VOLUME INFORMATION]
RAID Volumes::
ID Name Level Strip Size Status Bootable
0 Volume0 RAID5(Parity) 64KB 228.0GB Normal Yes
Physical Disks::
Port Device Model Serial # Size Type/Status(Vol ID)
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB Member Disk(0)
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB Member Disk(0)
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Member Disk(0)
3 HDS722580VLSA80 VNRB3EC20579SL 76.7GB Non-RAID Disk
[↑ ↓]Change [ESC]-Previous Menu [ENTER]-Select

(2) Delete RAID Volume

Here you can delete the RAID volume, but please be noted that all data on RAID drives will be lost.

Important

If your system currently boots to RAID and you delete the RAID volume in the Intel RAID Option ROM, your system will become unbootable.

Select option 2 **Delete RAID Volume** from the main menu window and press <Enter> key to select a RAID volume for deletion. Then press <Delete> key to delete the selected RAID volume. The following screen appears.

Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation. All Rights Reserved.
Name Level Drives Capacity Status Bootable
Volume0 RAID5(Parity) 3 228.0GB Normal Yes
[DELETE VOLUME VERIFICATION]
ALL DATA IN THE VOLUME WILL BE LOST!
Are you sure you want to delete "Volume0"? (Y/N):
Deleting a volume will reset the disks to non-RAID.
WARNING: ALL DISK DATA WILL BE DELETED.
[↑ ↓]Select [<ESC>]-Previous Menu [<DEL>]-Delete Volume

Press <Y> key to accept the volume deletion.

(3) Reset Disks to Non-RAID

Select option 3 **Reset Disks to Non-RAID** and press <Enter> to delete the RAID volume and remove any RAID structures from the drives. The following screen appears:


Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-07 Intel Corporation. All Rights Reserved.
[MAIN MENU]
1. Create RAID Volume
3. Reset Disks to Non- RAID
[RESET RAID DATA]
Resetting RAID disk will remove its RAID structures
and revert it to a non-RAID disk.
WARNING: Resetting a disk causes all data on the disk to be lost.
Port Drive Model Serial # Size Status
0 HDS722580VLSA80 VNRB3EC20548SL 76.7GB Member Disk(0)
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB
Select the disks that should be reset.
[↑ ↓]-Previous/Next [SPACE]-Selects [ENTER]-Selection Complete
[↑ ↓]-Select [ESC]-Exit [ENTER]-Select Menu

Press <Y> key to accept the selection.

Important

1. *You will lose all data on the RAID drives and any internal RAID structures when you perform this operation.*
2. *Possible reasons to 'Reset Disks to Non-RAID' could include issues such as incompatible RAID configurations or a failed volume or failed disk.*

Installing Driver

Install Driver in Windows Vista / XP / 2000

† **New Windows Vista / XP / 2000 Installation**

The following details the installation of the drivers while installing Windows XP / 2000.

1. When you start installing Windows XP and older operating systems, you may encounter a message stating, "Setup could not determine the type of one or more mass storage devices installed in your system". If this is the case, then you are already in the right place and are ready to supply the driver. If this is not the case, then press F6 when prompted at the beginning of Windows setup.
2. Press the "S" key to select "Specify Additional Device".
3. You should be prompted to insert a floppy disk containing the Intel® RAID driver into the A: drive.
   Note: For Windows Vista you can use Floppy, CD/DVD or USB.

Important

*Please follow the instruction below to make an **"Intel® RAID Driver"** for yourself.*

1. Insert the MSI CD into the CD-ROM drive.
2. Click the "Browse CD" on the Setup screen.
3. Copy all the contents in \\IDE\Intel\ICH9R\Floppy to a formatted floppy diskette.
*4. The driver diskette for **Intel® ICH9R RAID Controller** is done.*

4. For Windows Vista:
   During the Operating system installation, after selecting the location to install Vista click on "Load Driver" button to install a third party SCSI or RAID driver.
5. When prompted, insert the floppy disk or media (Floppy, CD/DVD or USB) you created in step 3 and press Enter.
6. Select "Intel(R) ICH8R/ICH9R SATA RAID Controller" an press ENTER.
7. The next screen should confirm that you have selected the Intel® RAID controller. Press ENTER again to continue.
8. You have successfully installed the Intel® Matrix Storage Manager driver, and Windows setup should continue.
9. Leave the disk in the floppy drive until the system reboots itself. Windows setup will need to copy the files from the floppy again after the RAID volume is formatted, and Windows setup starts copying files.

† **Existing Windows Vista/XP/2000 Driver Installation**

1. Insert the MSI CD into the CD-ROM drive.
2. The CD will auto-run and the setup screen will appear.
3. Under the Driver tab, click on ***Intel IAA RAID Edition***.
4. The drivers will be automatically installed.

† **Confirming Windows Vista/XP/2000 Driver Installation**

1. From Windows Vista/XP/2000, open the **Control Panel** from **My Computer** followed by the System icon.
2. Choose the **Hardware** tab, then click the **Device Manager** tab.
3. Click the "**+**" in front of the **SCSI and RAID Controllers** hardware type. The driver ***Intel(R) ICH9R SATA RAID Controller*** should appear.

Installing Software

Install Intel Matrix Storage Console

The Intel Application Accelerator RAID Edition driver may be used to operate the hard drive from which the system is booting or a hard drive that contains important data. For this reason, you cannot remove or un-install this driver from the system after installation; however, you will have the ability to un-install all other non-driver components.

Insert the MSI CD and click on the **Intel IAA RAID Editor** to install the software.



Click on this item

The **InstallShield Wizard** will begin automatically for installation showed as following:


Intel(R) Matrix Storage Manager - InstallShield(R) Wizard
Extracting Files
The contents of this package are being extracted.
Please wait while the InstallShield(R) Wizard extracts the files needed to install Intel(R) Matrix Storage Manager on your computer. This may take a few moments.
Reading contents of package...
InstallShield
< Back
Next >
Cancel

Click on the **Next** button to proceed the installation in the welcoming window.


Intel(R) Matrix Storage Manager 7.5.0.1017
Welcome to the setup for the Intel(R) Matrix Storage Manager.
This setup program will install Intel(R) Matrix Storage Manager onto your computer. It is strongly recommended that you exit all Windows programs before continuing setup.
< Back
Next >
Cancel
InstallShield Installation Framework

The window shows the components to be installed. Click **Next** button to continue.


Intel(R) Matrix Storage Manager 7.5.0.1017
Warning!
Please read the following information:
The driver you are about to install might be used to control the hard drive from which this computer is booting or to control a hard drive that contains important data.
For this reason, you cannot remove or uninstall this driver from the computer after installation. However, you can uninstall other, non-critical components. The following components can be uninstalled:
Intel(R) Matrix Storage Console
Help Documentation
Start Menu Shortcuts
System Tray Icon Service
Event Monitor Service
Click Next to continue the setup. Click Cancel to exit the setup.
< Back
Next >
Cancel
InstallShield Installation Frameworks

After reading the license agreement in the following window, click **Yes** button to continue.


Intel(R) Matrix Storage Manager 7.5.0.1017
License Agreement
Please read the following license agreement carefully. Press the Page Down key to view the rest of the agreement.
INTEL SOFTWARE LICENSE AGREEMENT (OEM / IHV / ISV Distribution & Single User)
IMPORTANT - READ BEFORE COPYING, INSTALLING OR USING.
Do not use or load this software and any associated materials (collectively, the "Software") until you have carefully read the following terms and conditions. By loading or using the Software, you agree to the terms of this Agreement. If you do not wish to so agree, do not install or use the Software.
Please Also Note:
* If you are an Original Equipment Manufacturer (OEM), Independent Hardware Vendor (IHV), or Independent Software Vendor (ISV), this complete LICENSE AGREEMENT applies;
You must accept all of the terms of the license agreement in order to continue the setup program. Do you accept the terms?
< Back
Yes
No
InstallShield Installation Frameworks

The following window appears to show the Readme File Information. It shows the system requirements and installation information.


Intel(R) Matrix Storage Manager 7.5.0.1017
Readme File Information
Refer to the Readme file below to view system requirements and installation information. Press the Page Down key to view the rest of the file.
* Installation Readme for Intel(R) Matrix Storage Manager.
* Refer to the system requirements for the operating
* systems supported by Intel(R) Matrix Storage Manager.
* This document makes references to products developed by
* Intel. There are some restrictions on how these products
* may be used, and what information may be disclosed to
* others. Please read the Disclaimer section at the bottom
* of this document, and contact your Intel field
* representative if you would like more information.
< Back
Next >
Cancel
Intel(R) Installation Frameworks

Once the installation is complete, the following window appears.

Intel(R) Matrix Storage Manager 7.5.0.1017
The setup for the Intel(R) Matrix Storage Manager is complete.
You must restart this computer for the changes to take effect. Would you like to restart the computer now?
Yes, I want to restart my computer now.
No, I will restart my computer later.
Click Finish, then remove any installation media from the drives.
< Back
Finish
Intel(R) Installation Frameworks

RAID Migration Instructions

The Intel Matrix Storage Console offers the flexibility to upgrade from a single Serial ATA (SATA) hard drive to RAID configuration when an additional SATA hard drive is added to the system. This process will create a new RAID volume from an existing disk. However, several important steps must be followed at the time the system is first configured in order to take advantage of RAID when upgrading to a second SATA hard drive:

1. BIOS must be configured for RAID before installing Windows on the single SATA hard drive. Refer to **On-Chip ATA Devices** for properly setting of the BIOS.
2. Install the Intel Application Accelerator RAID Driver during Windows Setup. Refer to **Installing Software** for instructions on installing the driver during Windows Setup.
3. Install the Intel Matrix Storage Console after the operating system is installed.

To create a volume from an existing disk, complete the following steps:

Important

*A **Create from Existing Disk** operation will delete all existing data from the added disk and the data cannot be recovered. It is critical to backup all important data on the added disk before proceeding. However, during the migration process, the data on the source disk is preserved.*

After the Intel Matrix Storage Console has been successfully installed and the system has rebooted, click on the Intel Application Accelerator shortcut link (**Start --> All Programs --> Intel Matrix Storage Manager --> Intel Matrix Storage Console**) and the following window will appear:



Create RAID Volume from Existing Disk

To create a RAID volume from an existing disk, choose **Action --> Create RAID Volume from Existing Hard Drive**.

Note: The "Action" button only appears in advance mode. To enable the advance mode, go to **View --> Basic mode** and click it.



The **Create RAID Volume from Existing Hard Drive Wizard** pops up to lead you for the following procedure. Click **Next** to continue.


Create RAID Volume from Existing Hard Drive Wizard
Welcome to the Create RAID Volume from Existing Hard Drive Wizard
This wizard migrates data from a single non-RAID hard drive to a new RAID volume.
Volume migration can take up to two hours depending on the size of the hard drives being used.
You may continue to use other applications during this time.
Select 'Next' to continue.
< Back
Next >
Cancel

(1) Step 1: Configure Volume

Here you can configure the new RAID volume by entering the volume name, selecting the RAID level and strip size.



† **RAID Volume Name:**

A desired RAID volume name needs to be typed in where the 'RAID_Volume1' text currently appears above. The RAID volume name has a maximum limit of 16 characters. The RAID volume name must also be in English alphanumeric ASCII characters.

† **RAID Level:**

Select the desired RAID level:

RAID 0 (Performance) – A volume optimized for performance will allow you to access your data more quickly.

RAID 1 (Redundancy) – A volume optimized for data redundancy will provide you with a realtime duplicate copy of your data. Note: Only half of the available volume space will be available for data storage.

RAID 5 (Useful) – RAID 5 can be used on three or more disks, with zero or more spare-disks. The resulting RAID-5 device size will be (N-1)*S, where N is the how many drive, S is the size of the smallest drive in the array. If one of the disks fail, all data are still intact. It can rebuild the disk from the parity information. If spare disks are available, reconstruction will begin immediately after the device failure. If two disks fail simultaneously, all data are lost. RAID-5 can survive one disk failure, but not two or more. Both read and write performance usually increase, but can be hard to predict how much. Reads are similar to RAID-0 reads, writes can be either rather

expensive (requiring read-in prior to write, in order to be able to calculate the correct parity information), or similar to RAID-1 writes. The write efficiency depends heavily on the amount of memory in the machine, and the usage pattern of the array. Heavily scattered writes are bound to be more expensive.

RAID 10 (Mirrored Stripes) – A RAID 1 array of two RAID 0 arrays.

† **Strip Sizes:**

Select the desired strip size setting. As indicated, the optimal setting is 128KB. Selecting any other option may result in performance degradation. Even though 128KB is the recommended setting for most users, you should choose the strip size value which is best suited to your specific RAID usage model. The most typical strip size settings are:

4KB: For specialized usage models requiring 4KB strips
8KB: For specialized usage models requiring 8KB strips
16KB: Best for sequential transfers
32KB: Good for sequential transfers
64KB: Good general purpose strip size
128KB: Best performance for most desktops and workstations

(2) Select the source disk

Then select the source disk that you wish to use and then click **"--->"** to move it to the **Selected** field. Then click **Next** to continue.

It is very important to note which disk is the source disk (the one containing all of the information to be migrated) and which one is the target disk. On a RAID Ready system, this can be determined by making a note during POST of which port the single disk is attached to.

You can also use the Intel Application Accelerator RAID Edition utility before the second disk is installed to verify the Port and serial number of the drive that contains all the data.


Create RAID Volume from Existing Hard Drive Wizard
Select Source Hard Drive
The data on the hard drive you select will be preserved and migrated across a new RAID volume.
Available
Port 0: HDT722516DLA380 - Serial
Port 1: HDT722516DLA380 - Serial
Port 2: HDS722580VLSA80 - Serial
Port 3: HDS722525VLSA80 - Serial
Selected
< Back
Next >
Cancel

(3) Select Member Hard Drive(s)

Then select the member disk (the target disk) that you wish to use and then click **"-->"** to move it to the **Selected** field. Then click **Next** to continue.

Please note that the existing data on the selected hard drive(s) will be deleted permanently. Do not forget to back up all the important data before continuing.


Create RAID Volume from Existing Hard Drive Wizard
Select Member Hard Drive(s)
Once the new RAID volume is created, it will span the source hard drive as well as 1 to 3 member hard drive(s).
Available
Port 1: HDT722516DLA380 - Serial
Port 2: HDS722580VLSA80 - Serial
Port 3: HDS722525VLSA80 - Serial
Selected
WARNING: Existing data on the selected hard drive(s) will be permanently deleted. Back up all important data before continuing.
< Back
Next >
Cancel


Create RAID Volume from Existing Hard Drive Wizard
Select Member Hard Drive(s)
Once the new RAID volume is created, it will span the source hard drive as well as 1 to 3 member hard drive(s).
Available
Port 2: HDS722580VLSA80 - Serial
Port 3: HDS722525VLSA80 - Serial
Selected
Port 1: HDT722516DLA380 - Serial
WARNING: Existing data on the selected hard drive(s) will be permanently deleted. Back up all important data before continuing.
< Back
Next >
Cancel

(4) Specify Volume Size

Specify the amount of available array space to be used by the new RAID volume. You may enter the amount in the space or use the slider to specify. It is recommended you use 100% of the available space for the optimized usage. For RAID 0 volume, if you do not specify 100% of the hard drive space, the rest hard drive space will be worked as RAID 1 volume, which is the new technology called Intel Matrix RAID. Then click **Next** to continue.


Create RAID Volume from Existing Hard Drive Wizard
Specify Volume Size
Use the fields or the slider below to specify the amount of available array space to be used by the new RAID volume.
Maximum Volume Size (GB):
306.7
Minimum Volume Size (GB):
154.9
Percentage of Available Space:
100
Volume Size (GB):
306.7
The minimum required size for the RAID volume is determined by the size of the source hard drive. If you create a volume that uses less than 100% of the hard drive space, you may create a second RAID volume to use the remaining space.
< Back
Next >
Cancel

(5) Start Creating RAID Volume from Existing Hard Drive Wizard

Before you continue the procedure of RAID volume creation from existing hard drive, read the dialogue box below carefully. Please note that once you click **Finish**, the existing data on the selected hard drive(s) will be deleted permanently and this operation cannot be undone. It is critical that you backup all important data before selecting **Finish** to start the migration process.


Create RAID Volume from Existing Hard Drive Wizard
Completing the Create RAID Volume from Existing Hard Drive Wizard
Volume migration can take up to two hours depending on the size of the hard drives being used.
You may continue to use other applications during this time.
WARNING: Completing this action will permanently delete existing data on the selected hard drive(s). Back up all important data before continuing.
Select 'Finish' to begin migrating data to the new volume.
< Back
Finish
Cancel

(6) Start Migration

The migration process may take up to two hours to complete depending on the size of the disks being used and the strip size selected. A dialogue window will appear stating that the migration process may take considerable time to complete, meanwhile a popup dialogue at the taskbar will also show the migration status. While you can still continue using your computer during the migration process, once the migration process starts, it cannot be stopped. If the migration process gets interrupted and your system is rebooted for any reason, it will pick up the migration process where it left off. You will be provided with an estimated completion time (the remaining time will depend on your system) once the migration process starts.

0% of Volume_0000 Migration Completed
Migration is in progress. When migration is complete, you will need to reboot your system to use the entire volume capacity.
To reopen this dialog at any point during the migration, right-click on the migrating volume while in the Advanced Mode of the Intel(R) Matrix Storage Console and select Show Migration Progress.
0% Complete - Time Remaining: 1 hr 32 min 57 sec

The following screen appears if the migration process is completed successfully. Then you have to reboot your system to use the full capacity of the new volume.


100% of Volume_0000 Migration Completed
Migration Status
The migration was completed successfully. The system will need to be rebooted to use the full capacity of the new volume.
Do you want to reboot the system now?
Yes
No
100% of Volume_0000 Migration Completed

Degraded RAID Array

A RAID 1, RAID 5 or RAID 10 volume is reported as degraded when one of its hard drive members fails or is temporarily disconnected, and data mirroring is lost. As a result, the system can only utilize theremaining functional hard drive member. To re-establish data mirroring and restore data redundancy, refer to the procedure below that corresponds to the current situation.

Missing Hard Drive Member

1. Make sure the system is powered off.
2. Reconnect the hard drive.
3. Reboot the system to Windows; the rebuild will occur automatically.

Failed Hard Drive Member

1. Make sure the system is powered off.
2. Replace the failed hard drive with a new one that is of equal or greater capacity.
3. Reboot the system to Intel RAID Option ROM by press <Ctrl> and <I> keys simultaneously during the Power-On Self Test (POST).


Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-06 Intel Corporation. All Rights Reserved.
RAID Volumes
ID Name Level Strip Size Status Bootable
0 Volume0 RAID10(RAID0+1) 64KB 153.4GB Degraded Yes
Physical Disks::
Port Device Model Serial # Size Type/Status(Vol ID)
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB Member Disk (0)
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB Member Disk (0)
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Member Disk (0)
3 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Non-RAID Disk
Press <CTRL-I> to enter Configuration Utility..

4. Select the port of the destination disk for rebuilding, and then press ENTER.


Intel(R) Matrix Storage Manager option ROM v7.5.0.1017 ICH9R wRAID5
Copyright(C) 2003-06 Intel Corporation. All Rights Reserved.
[MAIN MENU]
[DEGRADED VOLUME DETECTED]
Degraded volume and disk available for rebuilding detected. Selecting a disk initiates a rebuild. Rebuild completes in the operating system.
Select the port of the destination disk for rebuilding (ESC to exit):
Port Drive Model Serial # Size
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB
[↑ ↓]-Previous/Next [ENTER]-Select [ESC]-Exit
0 HDS722580VLSA80 VNRB3EC20549SL 76.7GB Member Disk (0)
1 HDS722580VLSA80 VNRB3EC20559SL 76.7GB Member Disk (0)
2 HDS722580VLSA80 VNRB3EC20569SL 76.7GB Member Disk (0)
3 HDS722580VLSA80 VNRB3EC20579SL 76.7GB Non-RAID Disk
[↑ ↓]Change [ESC]-Previous Menu [ENTER]-Select

5. Exit Intel RAID Option ROM, and then reboot to Windows system.
6. When prompted to rebuild the RAID volume, click 'Yes'.
7. The Intel(R) Storage Utility will be launched. Right-click the new hard drive and select 'Rebuild to this Disk'. The 'Rebuild Wizard' will be launched which will guide you through the process of rebuilding to the new hard drive.